

ACURA

SLX (96-97)
TL (96-98)

BUICK

Skylark (91-92)

CHEVROLET

Astro (90-94)
Beretta (90-96)
Blazer (90-93, 95)
Camaro (93)
Cavalier (93-95)
Corsica (93-96)
Express (96)
G-SeriesVan (90-96)
Lumina (90-94)
Metro (98-01)
Suburban (90-94)
Tracker (98)

CHRYSLER*

Lebaron (90-94)*
Town and Country (90-92, 96, 98)*

DODGE*

Caravan (90-92, 96, 98)*
Colt (90-94)*
D-Series Pickup (90-93)*
Dakota (90-96)*
Daytona (90-93)*
Dynasty (90-92)*
Grand Caravan (90-92, 96-98)*
Neon (95)*
Ram Truck (90-95)*
Ram Van (90-93)*
Shadow (93-94)*
Spirit (93-95)*
Stealth (91-92)*
W-Series Truck (90)*

EAGLE

Premier (90-92)
Summit (90-96)
Talon (90-93)

FORD

Aerostar (93-97)
Aspire (94-97)
Bronco (93)
Escort (93-98)
Expedition (97)
Explorer (95-97)
F-Series Truck (97)
FORD (cont.)
Festiva (90-93)
Mustang (90-93)
Probe (90-92)
Ranger (90-97)
Taurus (96-97)
Tempo (93-94)
Thunderbird (90-92)

GEO

Metro (90-92, 94-97)
Prizm (90-97)
Storm (90-93)
Tracker (90-97)

GMC

CK Series Truck (90-94)
G Series Van (90-92, 94-96)
Jimmy (90-92)
Safari (90-94)
Sonoma (91-94)
Suburban (90-94)
Syclone (91)
Typhoon (92)
Vandura (90-96)
Yukon (92-94)

HONDA

Accord (95-97)
Passport (96-97)

HYUNDAI

Accent (95-99)
Elantra (96-00)
Sonata (94-00)
Tiburon (97-01)

INFINITI

G20 (93-96)

I30 (96)

J30 (93-97)
Q45 (94-96)

ISUZU

Oasis (96-99)
Rodeo (96-97)
Trooper (93-97)
VehiCROSS (99-01)

LEXUS

LX450 (96-97)
LINCOLN
Continental (90-91)
Mark VII (90-92)
Town Car (90-92)

MAZDA

323 (90-95)
626 (90-92)
929 (90-92)
B-Series Truck (95-97)
Millenia (96-00)
MPV (93-98)
MX-3 (95)
MX-5 Miata (95-97, 99-00)
MX-6 (95-97)
Protege (96-00)

MERCURY

Capri (91-94)
Cougar (90-92)
Grand Marquis (90-92)
Mountaineer (97)
Sable (90-92, 96-97)
Topaz (90-94)
Tracer (91-97)
Villager (93-94)

MITSUBISHI

3000GT (91-95)
Diamante (96-98)
Eclipse (93-95)
Expo (92-95)
Galant (93-96)
Mirage (90-02)
Montero (90-94, 96-00)
Precis (90-94)

NISSAN

200SX (95-98)
240SX (95-98)
300ZX (93-96)
Altima (93-01)
Frontier (98-00)
Pathfinder (93-99)
Quest (94-02)
Sentra (95-99)
Xterra (00)

PLYMOUTH*

Acclaim (93-95)*
Grand Voyager (90-92, 96-98)*
Laser (90-94)*
Neon (95)*
Prowler (97-98)*
PLYMOUTH (cont.)
Sundance (90-94)*
Voyager (90-92, 96-98)*

PONTIAC

Firebird (90-92)
Grand Am (90-92)
Grand Prix (90)
Lemans (90-93)
Sunbird (90-94)
Sunfire (95)
Trans Sport (90-91)

SATURN

SC (91-95)
SL (91-95)
SW (93-95)

SUBARU

Forester (98-00)
Impreza (93-00)
Justy (93-94)
Loyale (93-94)

SUZUKI

Esteem (98-00)
Grand Vitara (99-00)
Sidekick (98)
Vitara (99-00)
X-90 (98)

TOYOTA

4Runner (90-98)
Avalon (95-97)
Avalon XL (95-97)
Camry (90-96)
Celica (90-99)
Corolla (90-02)
Cressida (90-92)
Land Cruiser (90-97)
MR2 (91-95)
Paseo (92-97)
Pickup (90-95)
Previa (91-97)
Rav4 (96-03)
Supra (90-98)
T100 (93-98)
Tacoma (95-01)
Tercel (90-99)
Tundra (00-02)

VOLKSWAGEN

Cabrio (95-97)
Cabriolet (90-93)
Corrado (90-95)
Eurovan (93-97)
Fox (90-93)
Golf (90-97)
GTI (90-97)
Jetta (90-97)
Passat (90-97)
Vanagon (90-91)

VOLVO

240 (93)
850 (93-94)
940 (93-95)
960 (93-94)

Important Notes

Your vehicle must be equipped with a factory-installed keyless entry system. While keyless entry is standard on most modern vehicles with power windows and power locks, it is not standard on all vehicles.

*All Chrysler, Dodge, Jeep, and Plymouth vehicles also require one existing, working remote paired to the vehicle to complete the pairing sequence of the Replacement Car Remote (to be used as the second remote).

To complete the "pairing" sequence which makes this remote usable with your vehicle, you must have at least one working key which can start the vehicle.

How does this remote compare to OEM factory remotes?

- More durable
- Longer battery life
- The same or greater range

3 EASY STEPS TO PAIRING

This remote was designed to be extremely easy to use. Follow these three simple steps to program your remote to your vehicle. No tools of any kind are required.

