

TV Codes / Códigos de TV / Codes de Téléviseur

Admiral.....	0093, 0463	Matsushita.....	0250
Advent.....	0761	Maxent.....	1755
Akai.....	0812, 1675, 0702, 1935	MB Quart.....	1868
AOC.....	1365, 1589, 2014, 2087, 2479	Megatron.....	0178, 0145
Apex Digital.....	0748, 0765, 1217, 2397	Memorex.....	0463, 0150, 0178, 1670, 1892
Audiovox.....	0451, 0802, 1766, 1769, 1868, 2121	MGA.....	0150, 0178
Aventura.....	0171	Midland.....	0000, 0017, 0051
Broksonic.....	0463, 1935,	Mitsubishi.....	1250, 0093, 0150, 0178
Carver.....	0054	Motorola.....	0093
Celebrity.....	0001	MTC.....	0060
Celera.....	0765	NAD.....	0156, 0178
Changhong.....	0765	NEC.....	1797
Citizen.....	0060, 1935,	NetTV.....	1755
Coby...1634, 2306, 2315, 2344, 2345, 2348		Nexus Electronics.....	2183
Commercial Solutions.....	1447, 0000	Nikko.....	0178
Crosley.....	0001, 0054	Norcent.....	0748, 1365, 1589
Curtis.....	2352, 2466	Olevia.....	1610, 1240, 1331
Curtis Mathes.....	0000, 0054, 0451, 0093,	Optimus.....	0250
.....	0060, 0702, 0145, 1661	Optoma.....	1348
Daewoo.....	0451, 1661,	Optonica.....	0093
Dell.....	1264	Orion.....	0463, 1463
Denon.....	0145	Panasonic.....	1480, 0250, 1457, 0051, 1291, 2264
Dumont.....	0017	2264
Durabrand.....	0463, 0178, 0171	PARK.....	2104, 2194
Dynex.....	1463, 2049, 2184	Penney.....	0000, 0156, 0051, 0060, 0178
Electroband.....	0001	Petters.....	1523
Electrograph.....	1755	Philco.....	0054, 0171, 1394, 1665, 1963
Electrohome.....	0463, 1670	Philips.....	1454, 1866, 0054, 1744, 1856, 2372, 2374
Element.....	1687, 1886, 2183	Pioneer.....	1457
Emerson.....	1864, 0451, 0463, 0178, 0171, 1661, 1394, 1665, 1963	Polaroid.....	1523, 0765, 1276, 1498, 1687, 1766, 1769, 2121
Emprex.....	1422	Portland.....	0451, 1661
Envision.....	1365, 1589, 2014, 2087	Prima.....	0761
ESA.....	0812, 0171, 1963	Prism.....	0051
Funai.....	0001, 0171, 1963	Proscan.....	1447, 0000, 2256
Gateway.....	1755	Proton.....	0178
GE.....	1547, 1447, 0000, 0051, 0451, 0178	Proview.....	1498, 1687
GFM.....	0171, 1665, 1963, 2167	Pulsar.....	0017
Gibraltar.....	0017	Quasar.....	0250, 0051
GoldStar.....	0178	RadioShack.....	0000, 0178
Haier.....	1748, 1749, 2309	RCA...1547, 1447, 0000, 0051, 0093, 1661, 1781, 2187, 2247, 2434,	
Hallmark.....	0178	Realistic.....	0178
Hannspree.....	1348	Runco.....	0017
Harman/Kardon.....	0054	Sampo.....	1755
Havermy.....	0093	Samsung.....	0812, 0060, 0702, 0178, 1060, 2051
Hello Kitty.....	0451	Sansui.....	0463, 0171, 1670, 1892, 1935
Hisense.....	0748, 1660, 2098, 2355	Sanyo.....	0054, 1142
Hitachi.....	1643, 0145	Sceptre.....	0878, 1217, 1360, 1599, 2506
iLo.....	1394, 1665, 1684	Scotch.....	0178
Infinity.....	0054	Scott.....	0178, 1711
Insignia.....	1423, 1564, 0463, 0171, 1660, 1710, 1892, 1963, 2049	Sears.....	0000, 0054, 0156, 0178, 0171
Inteq.....	0017	Sharp.....	0818, 0093
JBL.....	0054	Sheng Chia.....	0093
JCB.....	0001	Signature.....	0054
Jensen.....	0761	Sony.....	0810, 0001
JVC.....	0463, 0053, 1253, 1601, 1774, 2264	Soundesign.....	0178
KDS.....	1498, 1687	Soyo.....	1826
KLH.....	0765	Spectroniq.....	1498, 1687
LG.....	1423, 1447, 0017, 0178, 2358, 2424	Squareview.....	0171
LXI.....	0000, 0054, 0156, 0178	Superscan.....	0093
MAG.....	1498, 1687	Supreme.....	0001
Magnavox...1454, 1866, 1755, 0054, 0051, 0171, 0802, 1365, 1856, 1963, 2372		SVA.....	0748, 1963
Marantz.....	1454, 0054	Sylvania.....	1864, 0054, 0171, 1394, 1665,

.....	1886, 1963
Symphonic.....	0171
Syntax.....	1610, 1240, 1331
Tandy.....	0093
Technics.....	0250, 0051
Techwood.....	0051
Teknika.....	0054, 0150, 0060
Telefunken.....	0702
TMK.....	0178
TNCi.....	0017
Toshiba1524, 0156, 0060, 1291, 1935, 2006	
TVS.....	0463
Victor.....	0053
Vidikron.....	0054

Vidtech.....	0178
Viewsonic...1755, 0885, 1330, 1365, 1578, 1627, 1640, 1742, 2014, 2087, 2277	
Viore.....	1684, 2104, 2352
Vizio.....	1758, 0885
Wards.....	0001, 0000, 0054, 0017, 0156, 0051, 0060, 0178
Waycon.....	0156
Westinghouse.....	1712, 0451, 0885, 1217
White Westinghouse.....	0463, 1661
Wyse.....	1365
Zenith.....	0001, 1423, 0000, 0017, 0463, 0178, 0145, 1661, 1365

VCR / Magnétoscope

Accurian.....	0001	Memorex....0035, 0162, 0037, 0048, 0039, 0001, 0046	
Admiral.....	0048	MGA.....	0043
Adventura.....	0001	Minolta.....	0042
Aiko.....	0278	Mitsubishi.....	0067, 0043
Aiwa.....	0037, 0001	Motorola.....	0035, 0048
Allegro.....	0039	MTC.....	0001
America Action.....	0278	Multitech.....	0001
American High.....	0035	NEC.....	0067, 0038
Audiovox.....	0037, 0278	Nikko.....	0037
Calix.....	0037	Olympus.....	0035
Canon.....	0035	Optimus.....	0162, 0037, 0048
Carver.....	0081	Panasonic.....	0035, 0162
CCE.....	0278	Penney.....	0035, 0037, 0042, 0038
Citizen.....	0037, 0278	Pentax.....	0042
Craig.....	0037	Philco.....	0035
Crosley.....	0081, 0001	Philips.....	0739, 0035, 0081
Curtis Mathes.....	2000, 0035, 0162, 0278	Pilot.....	0037
Daewoo.....	0045, 0278	Pioneer.....	0067
Denon.....	0042	Polk Audio.....	0081
DirecTV.....	0739	Portland.....	0278
Durabrand.....	0039, 0038	Presidian.....	1593
Dynatech.....	0001	Proscan.....	2000
Electrohome.....	0037, 0043	Pulsar.....	0039
Electrohome.....	0037	Quarter.....	0046
Emerex.....	0032	Quartz.....	0046
Emerson.....	0037, 0001, 0043, 0278, 1593	Quasar.....	0035, 0162
Fuji.....	0035, 0033	RadioShack.....	0001
Funai.....	0001, 1593	Radix.....	0037
Garrard.....	0001	Randex.....	0037
GE.....	2000, 0035	RCA.....	2000, 0035, 0042
GFM.....	1593	Realistic.....	0035, 0037, 0048, 0001, 0046
GoldStar.....	0037, 0038	Runco.....	0039
Gradiente.....	0001	Samsung.....	0045
Harley Davidson.....	0001	Sanky.....	0048, 0039
Harman/Kardon.....	0081, 0038	Sansui.....	0001, 0067
Headquarter.....	0046	Sanyo.....	0046
Hitachi.....	0001, 0042	Scott.....	0045, 0043
Hughes Network Systems.....	0042	Sears.....	0035, 0037, 0001, 0042, 0046
Humax.....	0739	Sharp.....	0048
Instant Replay.....	0035	Signature.....	0035
JVC.....	0067	Sony.....	0032, 0035, 0033, 0001
KEC.....	0037, 0278	STS.....	0042
Kenwood.....	0067, 0038	Sylvania.....	0035, 0081, 0001, 0043, 1593
Kodak.....	0035, 0037	Symphonic.....	0001, 1593
Lloyd's.....	0001	Tashiko.....	0037
LXI.....	0037	Teac.....	0001
Magnavox...0035, 0039, 0081, 0001, 1593		Technics.....	0035, 0162
Marantz.....	0035, 0081	Teknika.....	0035, 0037, 0001
Marta.....	0037	Thomas.....	0001
Matsushita.....	0035, 0162	Tivo.....	0739
MEI.....	0035		

Toshiba.....	0045, 0043	Villain.....	0001
Totevision.....	0037	Wards.....	2000, 0035, 0048, 0039, 0081,
Vector.....	0045	0033,0045, 0001, 0042, 0038, 0046
Vector Research.....	0038	XR-1000.....	0035, 0001
Video Concepts.....	0045	Yamaha.....	0038
Videomagic.....	0037	Zenith.....	0037, 0039, 0033, 0001

DVD

Accurian.....	0675	Microsoft.....	0000
Akai.....	0695	Mitsubishi.....	1521, 0521
Allegro.....	0869	NAD.....	0741
Apex Digital.....	0672, 0830, 1061	Olevia.....	2331
Bel Canto Design.....	1571	Onkyo.....	0503, 0627, 2147
Blue Parade.....	0571	Panasonic.....	0490, 0503, 1641, 1762
Broksonic.....	0695	Philco.....	0675
California Audio Labs.....	0490	Philips.....	0503, 0539, 2056, 2084, 0646, 0675,
Cinea.....	0831	1267, 1354, 1506, 2434
CineVision.....	0869	Pioneer.....	0571, 0142, 0631, 1571, 2442
Citizen.....	0695	Polaroid.....	1061, 1316
Craig.....	0831	Polk Audio.....	0539
CyberHome.....	0816, 1129	Presidian.....	0675
Daewoo.....	0869, 1172	Proceed.....	0672
Denon.....	0490, 2258	Proscan.....	0000
Diamond Vision.....	1316	RCA.....	0000, 0571, 0822, 2213
Disney.....	0675, 1270	Rio.....	0869
DVD2000.....	0521	Rotel.....	0623
Emerson.....	0675	Sampo.....	0752
Funai.....	0675	Samsung.....	0490, 0573, 0199, 0820, 2069,
GE.....	0000, 0815	2369, 2556
GFM.....	0675	Sansui.....	0695
Go Video.....	0744, 0715, 0741, 0869	Sanyo.....	0695, 0873
GoldStar.....	0741, 0869	Schneider.....	0646
Grundig.....	0539	Sharp.....	0630, 0675, 0752, 2250
Harman/Kardon.....	1229	Shinonic.....	0533
Hello Kitty.....	0831	Sonic Blue.....	0869
Hitachi.....	0573, 0664	Sony.....	1633, 1533, 0533, 0864, 0772, 1070,
Hiteker.....	0672	1431, 1516
iLo.....	1348	Sylvania.....	0675
Insignia.....	0675, 2095, 2428, 2596	Symphonic.....	0675
Integra.....	0571, 0627, 2147	Technics.....	0490
JVC.....	0623, 0867, 1164, 1602, 2365	Theta Digital.....	0571
Kenwood.....	0490, 0534	Toshiba.....	0503, 0695, 2006, 2277, 2705
LG.....	0741, 0869, 1602	Urban Concepts.....	0503
Magnavox.....	0503, 0539, 0646, 0675,	Viore.....	2553
.....	1354, 1506	Vizio.....	2563
Marantz.....	0539	Xbox.....	0000
McIntosh.....	1533	Yamaha.....	0490, 0539, 0646, 0497, 0817
Memorex.....	0695, 0831, 1270, 2213	Zenith.....	0503, 0741, 0869

Satellite / Satélite / Satélite

Bell ExpressVu.....	0775	Mitsubishi.....	0749
DirecTV.....	1377, 0392, 0000, 0639, 1142,	Motorola.....	0869, 0856
.....	0749, 1749, 0819, 1076	Next Level.....	0869
Dish Network.....	0775, 1505	Panasonic.....	0701
Dishpro.....	0775, 1505	Philips.....	1142, 0749, 1749, 1076
Echostar.....	0775, 1505	Proscan.....	0392, 0000
Expressvu.....	0775	RadioShack.....	0869
GE.....	0000	RCA.....	0392, 0000, 0143
General Instrument.....	0869	Samsung.....	1377
GOI.....	0775	Sony.....	0639
Hitachi.....	0819	Star Choice.....	0869
HTS.....	0775	Tivo.....	1142
Hughes Network Systems.....	1142, 0749, 1749	Toshiba.....	0749, 1749, 0790
Jerrold.....	0869	Voom.....	0869
JVC.....	0775		

Cable / Cable / Câblesélecteur

Amino.....	1602, 1822	Pace.....	1376, 1877, 1982
Bright House.....	1376, 1877	Panasonic.....	1982
Cable One.....	1376, 1877	Pioneer.....	1877
Cablevision.....	1376, 1877, 1006	RCA.....	1256
Charter.....	1376, 1877, 2187	Rogers.....	1877
Cisco.....	1877, 1982	Scientific Atlanta.....	1877
Comcast.....	1376, 1877, 1982, 2576	Sejin.....	1602
Cox.....	1376, 1877	Shaw.....	1376
Digeo.....	1187, 2187	Sony.....	1006
i3 Micro.....	1602	Suddenlink.....	1376, 1877
Insight.....	1376, 1877	Thomson.....	1256, 1982
Knology.....	1877	Time Warner.....	1376, 1877, 2187
Mediacom.....	1376, 1877	Tivo.....	2576
Motorola.....	1376, 1187, 1982	WideOpenWest.....	1877
Myrio.....	1602, 1822		

Video Accessories / Accesorios de vídeo / Accessoires vidéo

Access HD.....	2185	Insignia.....	1415
ADB.....	2254	KoolConnect.....	1481
Airlink 101.....	2491	Lasonic.....	2348
Alpha Digital.....	2185	LG.....	1415
Amino.....	1481, 1615, 2482	Magnavox.....	1563
AMTC.....	2185	Memorex.....	2486
Apex Digital.....	2478	MicroGEM.....	2489
Artec.....	2490	Motorola.....	0858, 2378
AT&T.....	0858	Philco.....	1563
CASTI.....	2305	RCA.....	2325, 2454
Channel Master.....	2365	Sansonic.....	2348
Cisco.....	2345	Scientific Atlanta.....	0858, 2345
Coby.....	2667	Sunkey.....	2695
Coship.....	2487	SureWest.....	1481
Daewoo.....	2338	Sylvania.....	1563
Daytek.....	2305	Tivax.....	2185
Digital Stream.....	2303	Ventura.....	2454
Dish Network.....	2470	Venturer.....	2454
Echostar.....	2470	Verizon.....	2378
Epson.....	1563	Winegard.....	2454
GE.....	2360, 2450	Zenith.....	1415
Goodmind.....	2450	Zentech.....	2491
Gridlink.....	2348	Zinwell.....	2488

Digital TV Converter Boxes / Convertidores de TV Digital / Boîtes de conversion pour TV numérique

Access HD.....	2185	Insignia.....	1415
Airlink 101.....	2491	Lasonic.....	2348
Alpha Digital.....	2185	Magnavox.....	1563
AMTC.....	2185	Memorex.....	2486
Apex Digital.....	2478	MicroGEM.....	2489
Artec.....	2490	Philco.....	1563
CASTI.....	2305	RCA.....	2325, 2454
Channel Master.....	2365	Sansonic.....	2348
Coby.....	2667	Sunkey.....	2695
Coship.....	2487	Sylvania.....	1563
Daewoo.....	2338	Tivax.....	2185
Daytek.....	2305	Ventura.....	2454
Digital Stream.....	2303	Venturer.....	2454
Dish Network.....	2470	Winegard.....	2454
Echostar.....	2470	Zenith.....	1415
GE.....	2360, 2450	Zentech.....	2491
Goodmind.....	2450	Zinwell.....	2488
Gridlink.....	2348		