

TV Codes / Códigos de TV

Admiral.....	0093, 0463	Maxent.....	1755
Advent.....	0761	MB Quart.....	1868
Akai.....	0812, 1675, 0702, 1935	Megatron.....	0178, 0145
AOC.....	1365, 1589, 2014, 2087, 2479	Memorex.....	0463, 0150, 0178, 1670, 1892
Apex Digital.....	0748, 0765, 1217, 2397	MGA.....	0150, 0178
Audiovox.....	0451, 0802, 1766,	Midland.....	0000, 0017, 0051
.....	1769, 1868, 2121	Mitsubishi.....	1250, 0093, 0150, 0178
Aventura.....	0171	Motorola.....	0093
Broksonic.....	0463, 1935	MTC.....	0060
Carver.....	0054	NAD.....	0156, 0178
Celebrity.....	0001	NEC.....	1797
Celera.....	0765	NetTV.....	1755
Changhong.....	0765	Nexus Electronics.....	2183
Citizen.....	0060, 1935	Nikko.....	0178
Coby.....	1634, 2306, 2315, 2344, 2345, 2348	Norcent.....	0748, 1365, 1589
Commercial Solutions.....	1447, 0000	Olevia.....	1610, 1240, 1331
Crosley.....	0001, 0054	Optimus.....	0250
Curtis.....	2352, 2466	Optoma.....	1348
Curtis Mathes.....	0000, 0054, 0451, 0093,	Optonica.....	0093
.....	0060, 0702, 0145, 1661	Orion.....	0463, 1463
Daewoo.....	0451, 1661	Panasonic.....	1480, 0250, 1457,
Dell.....	1264	0051, 1291, 2264
Denon.....	0145	PARK.....	2104, 2194
Dumont.....	0017	Panney.....	0000, 0156, 0051, 0060, 0178
Durabrand.....	0463, 0178, 0171	Petters.....	1523
Dynex.....	1463, 2049, 2184	Philco.....	0054, 0171, 1394, 1665, 1963
Electroband.....	0001	Phillips.....	1454, 1866, 0054, 1744,
Electrograph.....	1755	1856, 2372, 2374
Electrohome.....	0463, 1670	Pioneer.....	1457
Element.....	1687, 1886, 2183	Polaroid.....	1523, 0765, 1276, 1498,
Emerson.....	1864, 0451, 0463, 0178,	1687, 1766, 1769, 2121
.....	0171, 1661, 1394, 1665, 1963	Portland.....	0451, 1661
Emprex.....	1422	Prima.....	0761
Envision.....	1365, 1589, 2014, 2087	Prism.....	0051
ESA.....	0812, 0171, 1963	Proscan.....	1447, 0000, 2256
Funai.....	0001, 0171, 1963	Proton.....	0178
Gateway.....	1755	Proview.....	1498, 1687
GE.....	1547, 1447, 0000, 0051, 0451, 0178	Pulsar.....	0017
GFM.....	0171, 1665, 1963, 2167	Quasar.....	0250, 0051
Gibraltar.....	0017	RadioShack.....	0000, 0178
GoldStar.....	0178	RCA.....	1547, 1447, 0000, 0051, 0093,
Haier.....	1748, 1749, 2309	1661, 1781, 2187, 2247, 2434
Hallmark.....	0178	Realistic.....	0178
Hannspree.....	1348	Runco.....	0017
Harman/Kardon.....	0054	Sampo.....	1755
Havermey.....	0093	Samsung.....	0812, 0060, 0702,
Hello Kitty.....	0451	0178, 1060, 2051
Hisense.....	0748, 1660, 2098, 2355	Sansui.....	0463, 0171, 1670, 1892, 1935
Hitachi.....	1643, 0145	Sanyo.....	0054, 1142
iLo.....	1394, 1665, 1684	Sceptre.....	0878, 1217, 1360, 1599, 2506
Infinity.....	0054	Scotch.....	0178
Insignia.....	1423, 1564, 0463, 0171,	Scott.....	0178, 1711
.....	1660, 1710, 1892, 1963, 2049	Sears.....	0000, 0054, 0156, 0178, 0171
Inteq.....	0017	Sharp.....	0818, 0093
JBL.....	0054	Sheng Chia.....	0093
JCB.....	0001	Signature.....	0054
Jensen.....	0761	Sony.....	0810, 0001
JVC.....	0463, 0053, 1253, 1601, 1774, 2264	Soundesign.....	0178
KDS.....	1498, 1687	Soyo.....	1826
KLH.....	0765	Spectroniq.....	1498, 1687
LG.....	1423, 1447, 0017, 0178, 2358, 2424	Squareview.....	0171
LXI.....	0000, 0054, 0156, 0178	Superscan.....	0093
MAG.....	1498, 1687	Supreme.....	0001
Magnavox.....	1454, 1866, 1755, 0054, 0051,	SVA.....	0748, 1963
.....	0171, 0802, 1365, 1856, 1963, 2372	Sylvania.....	1864, 0054, 0171,
Marantz.....	1454, 0054	1394, 1665, 1886, 1963
Matsushita.....	0250	Symphonic.....	0171

Syntax.....	1610, 1240, 1331
Tandy.....	0093
Technics.....	0250, 0051
Techwood.....	0051
Teknika.....	0054, 0150, 0060
Telefunken.....	0702
TMK.....	0178
TNCI.....	0017
Toshiba.....	1524, 0156, 0060, 1291, 1935, 2006
TVS.....	0463
Victor.....	0053
Vidikron.....	0054
Vidtech.....	0178

Cable Codes / Códigos de Cable

Amino.....	1602, 1822
Bright House.....	1376, 1877
Cable One.....	1376, 1877
Cablevision.....	1376, 1877, 1006
Charter.....	1376, 1877, 2187
Cisco.....	1877, 1982
Comcast.....	1376, 1877, 1982, 2576
Cox.....	1376, 1877
Digeo.....	1187, 2187
i3 Micro.....	1602
Insight.....	1376, 1877
Knology.....	1877
Mediacom.....	1376, 1877
Motorola.....	1376, 1187, 1982
Myrio.....	1602, 1822

Satellite Codes / Códigos de Satélite

Bell ExpressVu.....	0017	0775
DirecTV.....	1377, 0392, 0000, 0639,	0749
.....	1142, 0749, 1749, 0819, 1076	
Dish Network.....	0775, 1505	
Dishpro.....	0775, 1505	
Echostar.....	0775, 1505	
ExpressVu.....	0775	
GE.....	0000	
General Instrument.....	0869	
GO!.....	0775	
Hitachi.....	0819	
HTS.....	0775	
Hughes Network Systems.....	1142, 0749, 1749	
Jerrold.....	0869	
JVC.....	0775	

Viewsonic.....	1755, 0885, 1330, 1365, 1578,
.....	1627, 1640, 1742, 2014, 2087, 2277
Viore.....	1684, 2104, 2352
Vizio.....	1758, 0885
Wards.....	0001, 0000, 0054, 0017, 0156,
.....	0051, 0060, 0178
Waycon.....	0156
Westinghouse.....	1712, 0451, 0885, 1217
White Westinghouse.....	0463, 1661
Wyse.....	1365
Zenith.....	0001, 1423, 0000, 0017,
.....	0463, 0178, 0145, 1661, 1365

Pace.....	1376, 1877, 1982
Panasonic.....	1982
Pioneer.....	1877
RCA.....	1256
Rogers.....	1877
Scientific Atlanta.....	1877
Sejin.....	1602
Shaw.....	1376
Sony.....	1006
Suddenlink.....	1376, 1877
Thomson.....	1256, 1982
Time Warner.....	1376, 1877, 2187
Tivo.....	2576
WideOpenWest.....	1877

Video Accessories Codes / Códigos de Accesorios de vídeo

Access HD.....	2185
ADB.....	2254
Airlink 101.....	2491
Alpha Digital.....	2185
Amino.....	1481, 1615, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coby.....	2667
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network.....	2470
Echostar.....	2470
Epson.....	1563
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348

Insignia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Motorola.....	0858, 2378
Philco.....	1563
RCA.....	2325, 2454
Sansonic.....	2348
Cisco.....	2345
Sunkey.....	2695
SureWest.....	1481
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Verizon.....	2378
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

Digital TV Converter Boxes / Convertidores de TV Digital

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
CASTI.....	2305
Channel Master.....	2365
Coby.....	2667
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network.....	2470
Echostar.....	2470
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348

Insignia.....	1415
Lasonic.....	2348
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Philco.....	1563
RCA.....	2325, 2454
Sansonic.....	2348
Coby.....	2695
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Winegard.....	2454
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488