

Code List

TV Codes

Abex.....	172
Admiral.....	.001, 046, 047, 083, 095, 173, 191, 211
Adventura.....	174
Aiko.....	016
Akai.....	002
Alleron.....	.046, 047
Amtron.....	.038
Anam National.....	.003, 038, 192, 193, 194
AOC.....	.004, 005, 006, 007, 082, 195, 196
Apex.....	.236, 240, 241
Audiovox.....	.038
Belcor.....	.004
Bell & Howell.....	.001, 048, 049, 073, 083, 162
Bradford.....	.038
Broksonic.....	.000, 004, 250, 280
Brokwood.....	.004
Candle.....	.004, 006, 008, 132, 174, 196
Celebrity.....	002
Citizen.....	.004, 006, 008, 016, 038, 105, 132, 171, 196
Colortyme.....	.004, 006, 010, 196, 200
Concerto.....	.004, 006, 196
Contec/Cony.....	.012, 013, 038, 063
Craig.....	.038
Crosley.....	.000, 062
Crown.....	.038, 062, 130, 171
Curtis Mathes.....	.000, 004, 006, 015, 048, 049, 073, 105, 162, 171, 196, 212
CXC.....	.038
Daewoo.....	.004, 005, 006, 016, 017, 082, 127, 171, 190, 196, 202
Daytron.....	.004, 006, 171, 196
Dimensia.....	.000, 212
Dumont.....	.004, 151, 196, 217
Dynatech.....	.004
Electroband.....	.002
Electrohome.....	.000, 002, 003, 004, 006, 019, 020, 022, 064, 196
Emerson.....	.004, 006, 012, 023, 024, 025, 026, 027, 028, 029, 030, 031, 032, 033, 034, 035, 036, 037, 038, 039, 041, 042, 043, 044, 046, 047, 048, 049, 073, 123, 124, 162, 171, 177, 179, 191, 196, 208
Envision.....	.004, 006, 196
Fisher.....	.048, 049, 051, 073, 162, 180
Fujitsu.....	.046, 047
Funai.....	.038, 046, 047, 189
Futurtec.....	.038
GE.....	.000, 003, 004, 006, 022, 052, 054, 055, 064, 087, 100, 164, 165, 166, 167, 168, 181, 196, 203, 212, 213, 233
Gilbralter.....	.004, 151
Goldstar.....	.004, 005, 006, 012, 019, 056, 057, 058, 082, 155, 156, 171, 172, 196
Grundig.....	.038, 046, 047, 171
Hallmark.....	.004, 006, 196
Harvard.....	.038
Hisense.....	.237
Hitachi.....	.004, 006, 012, 013, 059, 060, 061, 063, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 148, 150, 179, 185, 196, 198, 199
IMA.....	.038
Infinity.....	.062, 130
Janel.....	174
JBL.....	.062, 130
JCB.....	.002
JC Penney.....	.000, 004, 005, 006, 008, 013, 022, 052, 054, 055, 057, 058, 063, 064, 072, 082, 087, 100, 104, 105, 109, 132, 166, 167, 171, 172, 181, 196, 201, 203, 207, 212, 233
Jensen.....	.004, 006, 196
JVC.....	.012, 013, 054, 055, 060, 063, 065, 066, 067, 123, 157, 158, 159, 182, 239
Kawasho.....	.002, 004, 006, 196
Kenwood.....	.004, 006, 019, 196
KLH.....	.236, 240, 241
Kloss Novabeam.....	.038, 068, 069, 174, 183
KTV.....	.038, 070, 171, 177
LG.....	.005, 082
Loewe.....	.062, 130
Logik.....	.001, 083
Luxman.....	.004, 006, 196
LXI.....	.000, 006, 048, 049, 062, 071, 072, 073, 100, 109, 130, 162, 181, 196, 203, 207, 212, 233
Magnavox.....	.000, 004, 006, 008, 019, 062, 068, 069, 075, 076, 077, 088, 130, 131, 132, 133, 134, 183, 196, 219, 235
Majestic.....	.001, 083
Marantz.....	.004, 006, 059, 062, 078, 130, 196, 199
Megatron.....	.006, 059, 196, 199
Memorex.....	.001, 005, 006, 046, 047, 048, 049, 073, 082, 083, 162, 191, 196
MGA.....	.004, 005, 006, 019, 022, 051, 064, 079, 080, 082, 196
Midland.....	.054, 055, 151, 171, 172, 181
Minutz.....	.052
Mitsubishi.....	.004, 005, 006, 019, 022, 051, 064, 079, 080, 081, 082, 125, 135, 196
Montgomery Ward.....	.001, 083
Motorola.....	.003, 173
MTC.....	.004, 005, 006, 082, 105, 196
Multitech.....	.038
Multivision.....	.084
NAD.....	.006, 071, 072, 109, 136, 185, 196, 207
NEC.....	.003, 004, 005, 006, 010, 082, 196, 200
Nikko.....	.006, 016, 196
NTC.....	.016
Onwa.....	.038
Optimus.....	.136, 185
Optonica.....	.095, 173
Orion.....	.030, 035, 191, 208
Panasonic.....	.003, 054, 055, 062, 109, 130, 170, 214, 350, 351
Philco.....	.003, 004, 005, 006, 008, 012, 019, 062, 068, 069, 075, 077, 082, 088, 130, 132, 134, 183, 196
Philips.....	.002, 003, 004, 008, 012, 019, 062, 068, 069, 075, 076, 086, 087, 088, 130, 132, 134, 167, 183, 196
Pilot.....	.004, 171, 196
Pioneer.....	.004, 006, 090, 091, 092, 136, 179, 185, 196
Portland.....	.004, 005, 006, 016, 082, 171, 196
Price Club.....	.105
Prima.....	.238
Prism.....	.054, 055
PROSCAN.....	.000, 100, 181, 203, 212, 233
Proton.....	.004, 006, 012, 093, 196
Pulsar.....	.004, 151
Quasar.....	.003, 054, 055, 070, 109, 170, 214
Radio Shack.....	.000, 048, 049, 073, 162, 212
Radio Shack/Realistic.....	.004, 006, 012, 038, 048, 049, 073, 095, 162, 171, 172, 196
RCA.....	.000, 003, 004, 005, 006, 007, 019, 054, 055, 082, 096, 098, 099, 100, 101, 102, 103, 129, 179, 181, 188, 190, 196, 202, 203, 212, 215, 233, 281, 352
Runco.....	.151, 217
Sampo.....	.004, 006, 171, 172, 196, 242
Samsung.....	.004, 005, 006, 012, 013, 015, 017, 019, 082, 104, 105, 106, 171, 172, 196, 201, 204
Sansui.....	.191, 208, 282
Sanyo.....	.004, 048, 049, 073, 080, 107, 162, 169, 180, 196
Scotch.....	.006, 196
Scott.....	.004, 006, 012, 024, 035, 038, 046, 047, 196
Sears.....	.000, 004, 006, 013, 019, 046, 047, 048, 049, 051, 063, 066, 071, 072, 073, 100, 109, 110, 162, 180, 181, 189, 196, 203, 207, 212, 233
Sharp.....	.004, 006, 012, 026, 029, 095, 111, 112, 113, 122, 171, 173, 196
Shogun.....	.004, 196
Signature.....	.001, 083, 173
Simpson.....	.008
Sony.....	.002, 205, 216, 218
Soundesign.....	.004, 006, 008, 038, 046, 047, 132, 196
Squareview.....	.189
SSS.....	.004, 038
Starlite.....	.038
Supre-Macy.....	.174
Supreme.....	.002
Sylvania.....	.004, 006, 008, 019, 062, 068, 069, 075, 076, 077, 088, 116, 130, 132, 134, 161, 183, 196, 353
Symphonic.....	.026, 029, 033, 038, 046, 047, 155, 189
Tandy.....	.173
Tashiko.....	.072
Tatung.....	.003
Technics.....	.054, 055
Techwood.....	.004, 006, 054, 055, 196
Teknika.....	.001, 004, 005, 006, 008, 012, 013, 016, 038, 046, 047, 063, 076, 082, 083, 105, 132, 170, 171, 196, 214
Telecaption.....	.117
Tera.....	.004, 012, 093
TMK.....	.004, 006, 196
Toshiba.....	.000, 048, 049, 071, 072, 073, 105, 109, 117, 118, 160, 161, 162, 190, 201, 207, 283
Totevision.....	.171
Universal.....	.052, 087, 166, 167
Victor.....	.066, 182
Vidtech.....	.004, 005, 006, 196
Viking.....	.174
Wards.....	.000, 001, 004, 005, 006, 019, 024, 033, 046, 047, 052, 062, 068, 069, 075, 076, 082, 083, 087, 088, 095, 119, 120, 130, 134, 166, 167, 173, 183, 196, 212
White Westinghouse.....	.000, 001, 190, 191
Yamaha.....	.004, 005, 006, 019, 082, 196
Zenith.....	.000, 001, 004, 051, 083, 151, 152, 153, 154, 196, 210, 217

VCR Codes

Admiral.....	001	Mitsubishi.....	.029, 055, 056, 065, 066, 067, 068, 069, 070
Adventura.....	026071, 072, 073, 074, 084, 106, 113, 123
Aiko.....	027	Montgomery Ward.....	001, 075
Aiwa.....	026	Motorola.....	001, 021
Akai.....	.003, 005, 007, 008, 111, 112, 113, 119	MTC.....	013, 126
Allegro.....	145	Multitech.....	.013, 016, 026, 053, 061
American High.....	021	NEC.....	.009, 010, 011, 016, 018, 064, 076, 078, 079, 111, 123
Asha.....	013	Nikko.....	014, 054
Audio Dynamics.....	.009, 010	Noblex.....	013
Audiovox.....	.014, 054	Olympus.....	021
Beaumont.....	013	Optimus.....	.001, 014, 054
Bell & Howell.....	011	Optonica.....	096
Broksonic.....	.012, 025, 031, 135, 235	Orion.....	.000, 031, 086, 089, 130
Calix.....	.014, 054	Panasonic.....	.021, 022, 109, 125, 126, 127, 265, 266
Candle.....	.013, 014, 015, 016, 017, 018, 019	Pentax.....	.016, 055, 056, 084, 107, 120,
Canon.....	021, 022	Pentax Research.....	018
Capehart.....	020, 110	Philco.....	.021, 022, 062, 063
Carver.....	062	Philips.....	.021, 022, 062, 096, 124, 139
CCE.....	027, 061	Pilot.....	014
Citizen.....	.013, 014, 015, 016, 017, 018, 019, 027, 054	Pioneer.....	.010, 055, 080, 081, 123
Colortyme.....	009	Portland.....	.016, 017, 019, 110
Colt.....	061	PROSCAN.....	.000, 083, 086, 089
Craig.....	.013, 014, 023, 054, 061	Protec.....	061
Curtis Mathes.....	.000, 009, 013, 016, 018, 021, 022, 024	Pulsar.....	104
.....	.086, 087, 089, 091, 115	Quarter.....	011
Cybernex.....	013	Quartz.....	011
Daewoo.....	.015, 017, 019, 025, 026, 027, 028, 110	Quasar.....	.021, 022, 125
Daytron.....	061, 110	Radio Shack.....	.001, 014, 050, 054, 096
DBX.....	009, 010	Radio Shack/Realistic.....	.011, 013, 014, 021, 022, 023, 026
Dimensia.....	.000, 086, 089029, 049, 050, 054, 096
Dynatech.....	026	Radix.....	014, 054
Electrohome.....	.014, 029, 054	Randex.....	014
Electrophonic.....	014	RCA.....	.000, 003, 007, 013, 021, 022, 055, 056, 082, 083, 084
Emerson.....	.003, 007, 012, 014, 015, 021, 024, 025, 026, 029,085, 086, 087, 088, 089, 090, 091, 100, 107, 115, 120,
.....	.030, 031, 032, 033, 034, 036, 037, 038, 039, 040, 041, 042,	125, 140, 267
.....	.044, 045, 046, 047, 054, 065, 105, 113, 116, 117, 130, 136	Realistic.....	.001, 011, 013, 014, 015, 021, 022, 023, 026, 029,
Fisher.....	.011, 023, 048, 049, 050, 051, 052, 118049, 054, 096
Fuji.....	021, 119	Ricoh.....	128
Funai.....	026	Runco.....	104
Garrard.....	026	Samsung.....	.005, 013, 015, 033, 053, 112, 141, 142
GE.....	.000, 013, 021, 022, 053, 086, 087, 089, 091, 115, 120	Sanky.....	001, 104
Go Video.....	134, 137	Sansui.....	.010, 031, 092, 111, 123, 130
Goldstar.....	.009, 014, 018, 054, 057	Sanyo.....	.011, 013, 023, 143
Gradiente.....	026	Scott.....	.012, 015, 025, 032, 038, 065, 116
Harley Davidson.....	026	Sears.....	.000, 011, 014, 021, 023, 026, 028, 048, 049, 050, 051
Harman Kardon.....	009054, 055, 056, 084, 086, 089, 107, 118
Harwood.....	061	Sharp.....	.001, 017, 029, 094, 095, 096, 097
Headquarter.....	011	Shintom.....	.056, 061, 084, 098, 119
Hi-Q.....	023	Shogun.....	013
Hitachi.....	.026, 055, 056, 057, 084, 107, 111, 120	Signature.....	001
Instant Replay.....	021	Singer.....	.021, 061, 128
JCL.....	021	Sony.....	.098, 099, 119, 144
JC Penney.....	.009, 010, 011, 012, 013, 014, 021, 022, 051	STS.....	021, 107
.....	.054, 055, 056, 060, 061, 062, 084, 107, 118	Sylvania.....	.021, 022, 026, 062, 063, 065, 124, 268
Jensen.....	.055, 056, 084, 111	Symphonic.....	026
JVC.....	.009, 010, 011, 018, 111, 123, 138	Tandy.....	011
Kenwood.....	.009, 010, 011, 016, 018, 111, 123	Tashiko.....	014, 054
KLH.....	061	Tatung.....	111
Kodak.....	.014, 021, 054	Teac.....	.026, 085, 111
LG.....	.014, 054	Technics.....	021, 109
Lloyd's.....	026	Teknika.....	.014, 021, 022, 026, 054, 100, 129
Logik.....	061	TMK.....	.013, 024, 047
LXI.....	.014, 054	Toshiba.....	.015, 049, 051, 055, 065, 113, 116, 118
Magnavox.....	.021, 022, 062, 063, 104, 105, 108, 124	Totevision.....	.013, 014, 054
Magnin.....	013	Unitech.....	013
Marantz.....	.009, 010, 011, 016, 018, 021, 022, 062, 064, 076	Vector Research.....	.009, 010, 015, 016
Marta.....	014	Victor.....	010
Matsushita.....	021	Video Concepts.....	.009, 010, 015, 016, 113
MEI.....	021	Videosonic.....	013
Memorex.....	.001, 011, 013, 014, 021, 022, 023, 026, 031	Wards.....	.001, 013, 014, 015, 021, 022, 023, 026, 029, 054,
.....	.054, 104, 130055, 056, 061, 084, 088, 090, 096, 101, 102, 103
MGA.....	.029, 065, 113	107, 116
MGN Technology.....	013	XR-1000.....	.021, 026, 061
Midland.....	053	Yamaha.....	.009, 010, 011, 018, 111
Minolta.....	.055, 056, 084, 107	Zenith.....	.026, 098, 104, 119, 128, 130, 145

PVR/DVR Codes

RePlay.....	316	TiVo.....	315
-------------	-----	-----------	-----

DVD Player Codes

Aiwa.....	350	JBL.....	251
Allegro.....	510	JVC.....	.161, 252, 352, 386, 503
Apex.....	.372, 373, 374	Kenwood.....	380
Broksonic.....	500, 600	Konka.....	353, 354
Daewoo.....	375	Koss.....	.253, 254, 381
Emerson.....	.376, 377, 501	Lasonic.....	382
Funai.....	377	Magnavox.....	.162, 357, 358, 383
GE.....	.160, 370, 378	Memorex.....	384
Go Video.....	502	Mintek.....	385
Hitachi.....	351, 379	Mitsubishi.....	163

NAD	376
Onkyo	255, 387
Ortron	392
Panasonic	256, 257, 300, 301, 355, 388
Philips	162, 258, 356, 357, 358, 389, 504
Pioneer	165, 259, 390, 391
PROSCAN	160, 370
Qwestar	392
RCA	160, 260, 302, 370, 371, 393, 409, 505, 601
Samsung	394, 395, 396, 506, 507
Sansui	397, 602

Sanyo	359, 508
Sharp	398, 399, 400, 401
Sony	166, 261, 360, 361, 402, 403, 404, 509
Sylvania	303, 377
Toshiba	162, 167, 362, 363, 405, 406, 407, 603
Venturer	262
Xbox ®*	160
Yamaha	258
Zenith	364, 408, 510

*Requires use of Xbox ® DVD playback kit.

Portable DVD Player Codes

RCA	371	Sharp	399
-----------	-----	-------------	-----

CD Player Codes

ADC	200, 201, 220	Mitsubishi	229, 230
ADO	201	Nakamichi	232, 233
Aiwa	175, 203	NEC	184
Akai	205	Onkyo	186, 234, 235
Denon	208	Optimus	237, 238, 239
Dynatech	177	Panasonic	188
Emerson	178	Pioneer	189, 240
Fisher	179, 212, 213	RCA	190, 211
GE	216	Sanyo	250
Hitachi	180	Sears	207
Inkel	220	Sherwood	243
JVC	181, 221	Sony	195, 209, 244
Kenwood	183, 222, 224	Teac	245, 246, 247
Luxman	225	Technics	197
Marantz	185, 226	Toshiba	231
MCS	228	Yamaha	198, 199, 248

TV/VCR Combo Codes

	TV	VCR
Broksonic	250	235

TV/DVD Combo Codes

	TV	DVD		TV	DVD
Broksonic	280	600	Sansui	282	602
RCA	281	601	Toshiba	283	603

TV/VCR/DVD Combo Codes

	TV	VCR	DVD		TV	VCR	DVD
Panasonic	350	265	300	RCA	352	267	302
.....	351	266	301	Sylvania	353	268	303

VCR/DVD Combo Codes

	VCR	DVD		VCR	DVD
Broksonic	135	500	Samsung	141	506
Emerson	136	501	142	507
Go Video	137	502	Sanyo	143	508
JVC	138	503	Sony	144	509
Philips	139	504	Zenith	145	510
RCA	140	505			

Home Theater (HTIB) Systems Codes

	DVD	Audio		DVD	Audio
JBL	251	300	Philips	258	307
JVC	252	301	Pioneer	259	308
Koss	253	302	RCA	260	309
.....	254	303	Sony	261	310
Onkyo	255	304	Venturer	262	311
Panasonic	256	305			
.....	257	306			

Satellite Codes

Alphastar	079	Philips	085
Bell ExpressVu	078, 091	Primestar	076
Chaparral	056, 057	PROSCAN	047, 071, 080, 081, 093
Dish Network	078, 089, 091	RCA	047, 071, 080, 081, 093
Drake	058, 059	Realistic	063
Echostar	089	Sony	072
GE	047, 071, 080, 081, 093	Star Choice	076, 092
General Instruments	060, 061, 062	STS1	064
Hitachi	083, 084	STS2	065
Hughes Network Systems	077, 083, 090	STS3	066
JVC	082	STS4	067
Magnavox	085	Toshiba	068, 073
Motorola	047, 071, 080, 081	Uniden	086
Panasonic	075		

HDTV Tuner Codes

RCA	200
-----------	-----

Cable Box Codes

ABC	001, 003, 004, 005, 006, 007	Philips	011, 012, 013, 015, 019, 025, 030, 031, 032
Antronix	008, 009	Pioneer	033, 034
Archer	008, 009, 010, 011	PROSCAN	003
Cabletenna	008	RCA	000, 007, 049
Cableview	008	Realistic	009
Century	011	Regal	022, 035
Citizen	011	Regency	017
Colour Voice	012, 013	Rembrandt	003
Comtronics	015	Samsung	034
Contec	016	Scientific Atlanta	006, 036, 037, 038
Eastern	017	Signal	018
Garrard	011	Signature	003
GC Electronics	009	Sprucer	000
GE	000, 003	Standard Component	039, 044
Gemini	018, 019	Starcom	001, 007, 018
General Instruments	000, 001, 003, 046, 049	Stargate	018
Hamlin	020, 021, 022, 028, 035	Starquest	018
Hitachi	003	Tocom	004, 023
Jasco	011	Tusa	018
Jerrold	000, 001, 003, 005, 007, 018, 023, 024, 046, 049	TV86	027
Magnavox	025	Unika	008, 009, 011
Motorola	000, 003, 046	United Cable	001
Movie Time	027, 028	Universal	008, 009, 010, 011
NEC	005	Video Way	044
NSC	027, 028	View Star	015, 016, 025, 027
Oak	016, 029	Zenith	000, 050, 051
Panasonic	000, 048		

Audio System Codes

Aiwa	250, 251, 252, 253, 254, 255, 256, 268	Panasonic	270, 271, 305, 306
Denon	274	Philips	307
Harman Kardon	267	Pioneer	308
JBL	300	RCA	259, 264, 265, 266, 309
JVC	257, 267, 301	Sherwood	273
Kenwood	258	Sony	260, 261, 272, 310, 312
Koss	302, 303	Technics	270, 271
Onkyo	269, 304	Venturer	311
Optimus	275	Yamaha	262, 263

Laser Disc Player Codes

RCA	133
-----------	-----