

Blind Spot Detection System User Guide & Warranty

WARNING: To help avoid injuries, never use the Blind Spot Detection System as a replacement for checking the interior and exterior mirrors and looking over your shoulder before changing lanes. The Blind Spot Detection System is not a replacement for careful driving.


Overview:

The Blind Spot Detection System is designed to aid in detecting vehicles that may have entered the blind spot zone, which is represented by the vehicles in positions 1 & 2 of the diagram below. The detection area is on both sides of your vehicle, extending rearward from the exterior mirrors to approximately 30 feet beyond the bumper. The system is designed to alert you if vehicles, approaching from the rear, enter the blind spot zone.

Using your BSD:

The Blind Spot Detection System will turn on when you start the engine and begin driving forward above approximately 20 mph (installer can adjust this threshold).

Event	Turn Signal	System Action
No vehicle in Blind Spot	Off	NA
Vehicle in Blind Spot	Off	LED On – Solid Buzzer Off (if installed)
Vehicle in Blind Spot	On	LED On - Rapid Flash Buzzer On (if installed)



System limitations:

The Blind Spot Detection System does have limitations. Conditions such as severe weather or debris buildup on the sensor areas may limit vehicle detection.

Other situations that may limit Blind Spot Detection System include:

- Certain maneuvers of other vehicles as they enter and exit the blind spot zone.
- Vehicles passing through the blind zone at very fast rates.
- Several vehicles forming a convoy and passing through the blind zone.

False Alerts:

It is possible that the Blind Spot Detection System will trigger an alert even though there is no vehicle in the blind spot zone. If your vehicle is towing a trailer, the sensors could possibly detect the trailer and trigger the Blind Spot Detection System. The Blind Spot Detection System can detect objects such as; construction barrels, guard rails, lamp posts, etc. Occasional false alerts are normal.

3 YEAR LIMITED WARRANTY

Applies to Audiovox Series Control Modules and Sensors

AUDIOVOX ELECTRONICS CORPORATION (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 36 months from the date of original purchase, such defect(s) will be repaired or replaced with new or reconditioned product (at the Company's option) without charge for parts and repair labor.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the warranty center at the address shown below.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

THE COMPANY DOES NOT PROVIDE MONITORING OR COMMUNICATIONS SERVICES. THE COMPANY DOES NOT ASSUME ANY RESPONSIBILITY FOR SUCH SERVICE PROVIDED BY OMNILINK SYSTEMS, INC, OR OTHER NON-AFFILIATED INDEPENDENT COMPANY. PURCHASER ASSUMES FULL RESPONSIBILITY FOR SUCH SERVICE AND ANY NOTICE GIVEN TO OMNILINK SYSTEMS, INC, OR ANY OTHER SERVICE PROVIDER.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For customer or technical support please call Voxx Support:

1-800-645-4994

**9 AM – 6 PM (EST - Eastern)
Monday – Friday**

Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788 | 1-800-645-4994