




ANDROID

CarLink Guide for Android Users



CarLink Guide for Android Users



New Account Creation




After having CarLink installed, follow the steps below to begin using your system.

1. Download the CarLink application to your phone:
 - i. Open the SMS with the link to download the application.
 - ii. Select the link and follow the instructions. Android users will be taken to the Android Market place to download the app.
2. Launch the CarLink app. from your phone's application list.
3. Select "Create Account" from the menu.
 - i. Enter your email as the ID and a password, you will then need to accept the End User Agreement to complete the account creation.

Note: The user will remain logged in unless manually logged out.

4. You will automatically be directed to the Add Car screen to add your vehicle to the account. Follow the steps below to add your car to the account.



Add Car

You will be prompted to add a vehicle upon completion of creating an account in step 3 above.


1. Enter the 19 digit SIM number provided by the dealer.
2. Enter the one time use, 4 digit code provided by the dealer.
3. Enter a name for the vehicle (optional).
4. When complete, touch the Add button.




Login to Your Account

You must be logged into your account to control your vehicle with the CarLink App. From the menu screen select Login and enter your user name and password.

Note: Even if you close the CarLink App you will remain logged in until manually logged out. After logging out, the application will launch in Demo Mode until a user has logged in.






Password Recovery



If for whatever reason you have forgotten your password, follow the steps below to recover it.

1. From the login screen, select menu to pull up the login screen menu.
2. Touch the Lost Password button.
3. Enter the login email address you used to create your account.
4. Touch the Send button and your password will be emailed to you.





Logout




Even if you close the CarLink App you will remain logged in until manually logged out. If you plan to give someone else access to your phone but do not wish to give them access to your vehicle, it is a good idea to logout of the CarLink App to avoid unauthorized access to your vehicle. After logging out, the application will launch in Demo Mode until a user has logged in.

1. Select menu from the main screen.
2. Touch the Logout button






Enable Sound



This feature allows you to toggle response sounds on or off. To enable or disable sounds when successfully activating vehicle functions, follow the steps below.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Touch the Enable Sounds check box to toggle ON or OFF.

Enable Vibration




This feature allows you to toggle response vibrations on or off. To enable or disable a vibration response when successfully activating vehicle functions, follow the steps below.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Touch the Enable Vibration check box to toggle ON or OFF.




Enable Haptics



This feature allows you receive feedback when you touch screen buttons on the main vehicle control screen. To enable or disable feedback when touching screen buttons follow the steps below.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Touch the Enable Haptics check box to toggle ON or OFF.



Account Settings





Account settings

Edit account email/password

The Account Settings screen is where you will be able to edit your accounts email address or change your account password. If you need to change either of these, follow the steps listed below.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Select Account Settings.
4. Enter your new email address or password. You can change one or both of these at this time.
5. Touch OK to save your changes.



Account Time Zone





Account time zone

Eastern Time (US & Canada)

The Account Time Zone screen is where you will be able to edit your local time zone. Follow the steps listed below to edit your time zone.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Select Account Time Zone.
4. Select your time zone from the list.





Alert Recipients



Alert recipients




Add/remove recipients for alerts

This feature requires your system be installed with a compatible Code Alarm, Prestige or Pursuit brand alarm system. See your installation dealer for details.

Note: To toggle alerts on or off, refer to Car Settings in the next section.

Provided your CarLink system is installed and connected with a compatible Code Alarm, Prestige or Pursuit brand alarm system you will have the ability to send alert notices from the vehicle if the alarm system is trigger by an open door or the shock sensor. To add, change or remove alert recipients follow the steps listed below.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Select Alert Recipients.
4. From the menu select Add Recipient.
5. Select either Phone or Email and enter the appropriate information.
6. Touch OK to save your changes.



Car Settings




Car settings

Edit car names, alerting options

The Car Settings screen is where you will be able to edit the name of the vehicle.

This screen is also where you can select whether or not CarLink will notify you if your alarm system detects a door or shock sensor violation. This feature requires your system be installed with a compatible Code Alarm, Prestige or Pursuit brand alarm system. See your installation dealer for details.

1. Select menu from the main screen.
2. Touch the Settings button.
3. Select Car Settings.
4. Edit the Vehicle Name or select one or both of the check boxes to toggle the alerts on or off.
5. Touch OK to save your changes.



Adding a Vehicle to an Existing Account



You will be prompted to add a vehicle upon completion of creating a new account, to add an existing account, follow the steps below.

1. From the Menu screen, select Add Car.
2. Enter the 19 digit SIM number provided by the dealer.
3. Enter the one time use, 4 digit code provided by the dealer.
4. Enter a name for the vehicle (optional).
5. When complete, touch the Add button.

Multiple Vehicle Access and Control

If you have added more than one vehicle to your account follow the steps below to toggle between vehicle's

1. Select menu from the main screen.
2. Touch the Select Car button.
3. Select the vehicle from the list.



Buttons turn blue when activated.

Vehicle Access and Control

Use the icons on the Keypad Screen to operate the CarLink features for your vehicle. For more information and updates please visit the CarLink website, voxxcarlink.com.

Note: Once a feature is activated, the length of time your vehicle takes to respond will be affected by cellular coverage or network congestion.



Touch this icon to lock the vehicle.



Touch this icon to unlock the vehicle.



Touch this icon to locate the vehicle.



Touch this icon to remote start the vehicle. The vehicle will remain running for the preprogrammed run time set by the installation center.

AUX 1 Touch this icon to activate AUX 1, if equipped.

AUX 2 Touch this icon to activate AUX 2, if equipped.

