




BlackBerryTM

CarLink Guide for BlackBerry Users



CarLink Guide for BlackBerry Users



New Account Creation

After having CarLink installed, follow the steps below to begin using your system.

1. Download the CarLink application to your phone:
 - i. Open the SMS with the link to download the application.
 - ii. Select the link and follow the instructions. BlackBerry users will be taken to the BlackBerry App World to download the app.

2. Launch the CarLink app. from your phone's application list.

3. Select "Create Account" from the menu.
 - i. Enter your email as the ID and a password, you will then need to accept the End User Agreement to complete the account creation.

Note: The user will remain logged in unless manually logged out.

4. You will automatically be directed to the Add Car screen to add your vehicle to the account. Follow the steps below to add your car to the account.

A screenshot of the "Car Link - Create Account" screen. It has a black background with white text. At the top, it says "Car Link - Create Account". Below that are three input fields: "Email", "Password", and "Confirm password". At the bottom, there are two buttons: "Create" and "Cancel".A screenshot of the "Car Link - Add Car" screen. It has a black background with white text. At the top, it says "Car Link - Add Car". Below that are three input fields: "SIM ID", "Car name", and "Passcode (4 digits)". At the bottom, there are two buttons: "Create" and "Cancel".

Add Car

You will be prompted to add a vehicle upon completion of creating an account in step 3 above.


1. Enter the 19 digit SIM number provided by the dealer.
2. Enter the one time use, 4 digit code provided by the dealer.
3. Enter a name for the vehicle (optional).
4. When complete, touch the Add button.

Login to Your Account

You must be logged into your account to control your vehicle with the CarLink App. From the menu screen select Login and enter your user name and password.

Note: Even if you close the CarLink App you will remain logged in until manually logged out. After logging out, the application will launch in Demo Mode until a user has logged in.

A screenshot of the "Car Link - Login" screen. It has a black background with white text. At the top, it says "Car Link - Login". Below that are two input fields: "Email" and "Password". At the bottom, there is a "Login" button.





Password Recovery



If for whatever reason you have forgotten your password, follow the steps below to recover it.

1. From the login screen, pull up the login screen menu.
2. Select the Forgot Password from the list.
3. Enter the login email address you used to create your account.
4. Select Send and your password will be emailed to you.




Logout



Even if you close the CarLink App you will remain logged in until manually logged out. If you plan to give someone else access to your phone but do not wish to give them access to your vehicle, it is a good idea to logout of the CarLink App to avoid unauthorized access to your vehicle.

1. Pull up the home screen menu.
2. Select Logout.







Enable Vibration



This feature allows you to toggle response vibrations on or off. To enable or disable a vibration response when successfully activating vehicle functions, follow the steps below.

1. Pull up the home screen menu.
2. Select Settings.
3. Select the Enable Vibration check box to toggle ON or OFF.







Account Settings



Email - Password - Time Zone

The Account Settings screen is where you will be able to edit your accounts email address or change your account password. This is also where you will be able to edit your local time zone. If you need to change either of these, follow the steps listed below.

1. Pull up the home screen menu.
2. Select Settings.
3. Select Account Settings.
4. Enter or change the desired information:
Email
Password
Time Zone
5. Select Save to save your changes.



Alert Recipients



This feature requires your system be installed with a compatible Code Alarm, Prestige or Pursuit brand alarm system. See your installation dealer for details.

Note: To toggle alerts on or off, refer to Car Settings in the next section.

Provided your CarLink system is installed and connected with a compatible Code Alarm, Prestige or Pursuit brand alarm system you will have the ability to send alert notices from the vehicle if the alarm system is triggered by an open door or the shock sensor. To add, change or remove alert recipients follow the steps listed below.

1. Pull up the home screen menu.
2. Select Settings.
3. Select Alert Recipients.
4. Pull up the menu and select Add Recipient.
5. Select either Phone or Email and enter the appropriate information.
6. Select Save to save your changes.




Car Settings



The Car Settings screen is where you will be able to edit the name of the vehicle.

This screen is also where you can select whether or not CarLink will notify you if your alarm system detects a door or shock sensor violation. This feature requires your system be installed with a compatible Code Alarm, Prestige or Pursuit brand alarm system. See your installation dealer for details.

1. Pull up the home screen menu.
2. Select Settings.
3. Select Car Settings.
4. Edit the Vehicle Name or select one or both of the check boxes to toggle the alerts on or off.
5. Select Save to save your changes.



Adding a Vehicle to an Existing Account


You will be prompted to add a vehicle upon completion of creating a new account, to add an existing account, follow the steps below.

1. Pull up the home screen menu.
2. Select Add Car.
3. Enter the 19 digit SIM number provided by the dealer.
4. Enter the one time use, 4 digit code provided by the dealer.
5. Enter a name for the vehicle (optional).
6. When complete, select the Create button.

Multiple Vehicle Access and Control

If you have added more than one vehicle to your account follow the steps below to toggle between vehicle's

1. Select the vehicle from the main screen.
2. Select the vehicle from the list.



Vehicle Access and Control

Use the icons on the Home Screen to operate the CarLink features for your vehicle. For more information and updates please visit the CarLink website, voxxcarlink.com.

Note: Once a feature is activated, the length of time your vehicle takes to respond will be affected by cellular coverage or network congestion.



Buttons turn blue when activated.



Touch this icon to lock the vehicle.



Touch this icon to unlock the vehicle.



Touch this icon to locate the vehicle.



Touch this icon to remote start the vehicle. The vehicle will remain running for the preprogrammed run time set by the installation center.

AUX 1

Touch this icon to activate AUX 1, if equipped.

AUX 2

Touch this icon to activate AUX 2, if equipped.

