


PLAY INTERNAL VIDEO GAMES

- Press the **MODE** button on the front control panel (or **SOURCE** on the remote control) until "INTERNAL GAME" appears on the screen.
- Turn ON and set the game controller to channel "A" or channel "B" depending on which unit you will play on.
- Use the game controller's left and right arrow keys to choose a game.
- Press the **START** button on the game controller to choose the game.
- Use the "A & B" buttons for fire, jump or other action.
- Press **RESET** to return to the main menu.



Note: If the flashing LED stays illuminated, replace the batteries.

LISTEN OVER VEHICLE SPEAKERS

- Press the **SPEAKER**  on the remote (FIG 2) or on the front control panel (FIG 1). "SPEAKER SOUND ON FM ___:___ PRESS LEFT OR RIGHT TO ADJUST" will appear on the screen as shown at right.
- Turn vehicle's radio on, and tune to the FM frequency displayed on screen. If radio interference is heard, try another frequency (see pages 13 & 15 in your Owner's Manual for more information).

