

Model AVX1B4S

Transmitter Programming Guide

This transmitter is designed for use with your upgrade remote start unit and is programmed by using the remote start's program switch in combination with the transmitter button. Although this transmitter can be programmed into any of the Audiovox remote start and or alarm, alarm remote start systems, it will offer limited use and should be used for the remote start upgrade only.

To program this transmitter into your remote start upgrade unit:

- 1) Turn the ignition to the on position
- 2) Press and release the programming switch 3 times
- 3) Press and hold, for 3 seconds, the button of the transmitter you wish to add until the parking light flashes indicating the transmitter has been learned.
- 4) Repeat step 3 for each transmitter up to a total of 4. Turn the ignition off to exit the program mode.

NOTE: Do not allow more than 15 seconds to lapse between steps or the program mode will be automatically exited and you will have to start over.

128-6833 1 of 2

\bigcirc	ORDER FOR	RM FOR TF	ANSMITTER AV	/X1B4S
Ö	Important: To h	nelp us expeo legibly and n	dering Departmer dite your order, pleas nail this form and yo below.	se print all of
1) Name	:			
2) Addr	ess:			
3) City:_		State:	Zip Code:	
4 Teleph	one Number:()		
Cost Pe	Number Of Trans Transmitter is: By Number Of Tr	•	\$65.00	
(New)	Total Amount En ′ork State Reside d of Payment:		lude the appropriate	sales tax)
Mast			or Money Order (do no Audiovox Corporation	
Credit C	ard Number:			
Credit C	ard Expiration Da	ate:	//	
,		tter Orderii	ng Department cus Blvd., Hauppa	uge N.Y.
	transmitters by	phone. Simp	order additional or rep ly dial 1 - 800 - 645 - the operator interfa	4994, and

© 2003 Audiovox Electronics Corp., Hauppauge, N.Y. 11788 128-6833

128-6833 2 of 2