

BT-HP1

OWNERS MANUAL

Bluetooth® is a trade mark of Bluetooth Special Interest Group (SIG) Inc.

WARNING! Never disassemble or adjust the unit.

WARNING! To prevent injury from shock or fire, never expose this unit to moisture or water.

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

INTRODUCTION

The BT-HP1 is a Bluetooth® stereo headset. The stereo headset is foldable and the retractable design makes the stereo headset is very easy to take with you. The stereo headset supports the following Bluetooth® profiles:

HSP —— Headset Profile

HFP —— Hands-free Profile

A2DP—— Advanced Audio Distribution Profile

AVRCP——Audio/Video Remote Control Profile


Please read this user manual carefully before use.

The BT-HP1 provides the following features:

- 1) When paired with a Bluetooth® cell phone or PDA supporting Hands-free Profile you can:
 - Answer a call, end a call, and reject a call
 - Redial last number
 - Voice dial if supported by your cell phone
 - Adjust the volume
 - Transfer a call between the headset and your Bluetooth® cell phone
 - Microphone mute
- 2) When paired with a Bluetooth® music device or Bluetooth® transmitter supporting Advanced Audio Distribution Profile you can:
 - Enjoy music wirelessly
 - Adjust the volume
 - Pause/play using remote control
 - Select the previous/next track using remote control
- 3) Switch easily between a phone call and music. Incoming calls will not be lost while you listen to music.
- 4) Every time the headset is turned on, it will connect to last connected device automatically.

Note: Even though the paired device and the headset support the same Bluetooth® profiles, functions may vary due to different manufacturers or specification differences between devices.

CONTROLS AND INDICATORS



1	Foldable and retractable headband
2	+ button: Volume up
3	< button: Previous track
4	> button: Next track
5	Built-in microphone
6	LED indicator
7	Multi-Function Button (MFB): Power on/power off/answer a call/end a call/reject a call/microphone mute/call transfer/redial last number/voice dial/pause/play
8	Charging jack
9	- button: Volume down

OPERATION

Charging the headset

The stereo headset comes with a built-in rechargeable battery. Prior to using the stereo headset it is recommended to charge the battery fully for the first time. The charging time is about three hours. When the stereo headset battery is low, the red LED flashes twice and the headset emits three tones every 20 seconds. Please recharge the headset battery.

Using the USB cable

Connect the USB cable to a computer USB port and the 2.5mm plug to the charging jack of the headset. The red LED is on while charging. The charging time is about three hours to charge the battery fully. When charging cycle is completed, the red LED will turn off.

Note: The USB cable can vary based on different countries or areas and actual demands.



The battery is recyclable

WARNING! Do not expose the battery to excessive heat or fire. Follow applicable regulations when disposing of the battery.

Turning the stereo headset on and off

Function	Action	LED indicator
Power on	Press and hold MFB button for 3 to 5 seconds until blue LED flashes	Blue LED flashes every second
Power off	Press and hold MFB button for 3 to 5 seconds until red LED flashes	Red LED flashes once for 1 second

Note: In order to save the battery charge, the stereo headset will turn off automatically after five minutes if no devices are connected to the stereo headset.

Enter pairing mode

Function	Action	LED indicator
Entering pairing mode	Ensure the headset is turned off. Press and hold MFB button for 6 to 7 seconds until LED flashes red and blue alternately	LED flashes red and blue alternately

Note: Pairing mode will last two minutes. If no devices can be connected after two minutes, the stereo headset will return to standby mode automatically.

Pairing the stereo headset with a Bluetooth® cell phone

Prior to using the headset for the first time, you have to pair it with a Bluetooth® capable cell phone. The pairing procedures can differ between cell phone models and manufacturers. Please refer to your cell phone user's manual for further information. The general pairing procedures are as follows:

1. Place the stereo headset and Bluetooth® cell phone approximately three feet apart without physical obstructions such as walls etc.
2. Enter the headset's pairing mode (please refer to Entering pairing mode).
3. Activate your cell phone's Bluetooth® function and set your cell phone to search for Bluetooth® devices.
4. Select BT-HP1 from the list of devices shown on the cell phone.
5. If and when prompted enter password or PIN "0000".
6. If prompted by your cell phone to connect, accept the prompt "Yes" (this will vary among cell phone models).
7. Once the stereo headphones and the cell phone have paired, the blue LED flashes twice or three times every 4 seconds.

Note: If the pairing process fails, turn off the headset first and repeat steps 1 through 6 above.

After pairing is successful, the headset and the cell phone will remember each other, and will not require pairing again. The headset can remember up to 8 paired devices. When the number of paired devices exceeds 8, the first one will be removed and replaced.

Every time the headset is turned on, it will connect to last connected device automatically. If you want to pair it with another device, please turn off the Bluetooth® function of the last connected devices first. Pair the headset with the new device according to steps 1 through 6 above.

Pairing the stereo headset with a Bluetooth® audio device

You can connect the stereo headset to a Bluetooth® audio device transmitter to listen to music wirelessly. Perform the following steps to pair the device to the stereo headset:

1. Place the stereo headset and Bluetooth® audio device transmitter approximately three feet apart without physical obstructions such as walls etc.
2. Enter the headset's pairing mode (please refer to Entering pairing mode).
3. Activate your audio device transmitter Bluetooth® function and set your audio device transmitter to search for Bluetooth® devices and send a pairing request.
4. When the stereo headset requests a password the Bluetooth® audio device transmitter will respond with "0000" automatically.
5. Once the stereo headphones and the Bluetooth® audio device have paired, the blue LED flashes twice every 4 seconds.

Note: *The pairing password of the stereo headset is "0000". The stereo headset can only pair with a Bluetooth® transmitter whose pairing password is "0000". If the pairing process still fails after several attempts, refer to the Bluetooth® audio device transmitter documentation or further information.*

Multi-Pairing the stereo headset

The stereo headset can connect with a maximum of two devices simultaneously. One device is a Bluetooth® cell phone supporting HFP profile, while the other device is a Bluetooth® audio device supporting A2DP profile. If you want to multi-pair, perform the following:

1. First, pair the stereo headset with a Bluetooth® audio device transmitter (refer to Pairing the stereo headset with a Bluetooth® audio device).
2. Turn off the Bluetooth® transmitter.
3. Pair and connect the headset with a Bluetooth® cell phone (refer to Pairing the stereo headset with a Bluetooth® cell phone").
4. Turn on the Bluetooth® transmitter, it will connect to the headset automatically.

Note: *After a successful multi-pairing, the paired devices will remember each other. Unless pairing information is deleted because of a new pairing, they will no longer need to pair next time. If the pairing information is deleted, please connect the cell phone with the stereo headset first and then turn on the Bluetooth® transmitter at which time multi-pairing can be performed. For the cell phones which support the HSP and A2DP at the same time, pairing with stereo headset may occur simultaneously. In this situation, the Bluetooth® audio device transmitter may not connect to the headset. 3.*

Re-connecting with a Bluetooth® device

a) Automatic connecting

Every time the stereo headset is turned on, it will connect to last connected device automatically.

b) Manual connecting

When the headset doesn't connect to a device supporting HFP, press the MFB button twice and the stereo headset will connect to last connected HFP device.

When the headset doesn't connect to a device supporting A2DP, quickly press MFB button once and the stereo headset will connect to last connected A2DP device.

Note: Before connecting to a Bluetooth® device, please turn on the Bluetooth device's Bluetooth function. On some Bluetooth® devices, such as Nokia cell phones for example, you have to allow automatic connecting in the cell phone's settings. Please refer to your cell phone's documentation for further information.

Wearing the headset

The headband of the headset is foldable and retractable. Adjust the stereo headset to fit your head comfortably. Each side of the stereo headset is marked. Place the stereo headset on the appropriate side according to the right/left mark on the ear pieces.

Stereo Headset Phone Functions

Function	Action
Cancel a call	Quickly press the MFB button.
Answer a call	Quickly press the MFB button.
Reject a call	Press and hold MFB button for 2 seconds. Release MFB button and a tone is heard.
End a call	Quickly press the MFB button.
Volume up	Touch and hold the + button. The volume will increase to a maximum level.
Volume down	Touch and hold the - button. The volume will decrease to a minimum level.
Call transfer (stereo headset to mobile phone)	Press and hold MFB button for 2 seconds. Release MFB button when a tone is heard.
Call transfer (mobile phone to headset)	Press and hold MFB button for 2 seconds. Release MFB button when a tone is heard.
Muting the microphone	Quickly press the MFB button twice.
Cancel mute	Quickly press the MFB button twice.
Voice dial	Press and hold MFB button for 2 seconds. Release MFB button when a tone is heard.
Redial last number	Quickly press the MFB button twice.
Lock/unlock the buttons	Press and hold MFB and + button for 2 seconds. Release the buttons when a tone is heard.
Clear pairing list while stereo headset is charging	Press and hold MFB button. Then press and hold the - button for 5 seconds. Release the button when a tone is heard. The LED will flash red once.

Stereo Headset Phone Function (Three Way Call)

Function	Action
End current call and answer a new incoming call	Quickly press the MFB button once.
Keep current call and answer a new incoming call	Quickly press the MFB button twice.
Call transfer (Pick up another call while on a call)	Quickly press the MFB button twice.

Note: Not all cell phones support all functions listed above. Please refer to your cell phone's documentation manual for further information. Certain functions and indication tones may vary with different models of cell phones. When the volume is adjusted to the maximum or minimum settings you will hear a tone. When pressing the answer button on some cell phones, the call will be transferred to the cell phone. In this case you have to switch the call to the headset manually.

Stereo Headset Phone Music Playback Function

Once the stereo headset is paired to a Bluetooth® cell phone or Bluetooth® transmitter supporting the A2DP profile you can listen to enjoy music on the headset.

Function	Action
Volume up	Touch the + button. Touch and hold the + button the volume will increase to maximum.
Volume down	Touch the - button. Touch and hold the - button the volume will decrease to minimum.
Pause	Quickly press the MFB button.
Play	Quickly press the MFB button.
Previous track	Touch the < button.
Next track	Touch the > button.

Note: When playing music on some cell phones, the music will be transmitted to the cell phone's speaker instead of the headset. You have to select "transmit the sound via Bluetooth" in the settings menu and then choose "BT-HP1" as speaker device. The music will then be transmitted to the headset. Please refer to your cell phone's documentation further information. If you want to remote control previous/next track, pause/play, the stereo headset requires your Bluetooth® cell phone or Bluetooth® transmitter to be paired with the headset and support AVRCP profile. Please refer to your cell phone's documentation further information.

Stereo Headset LED Status Indicator

When the stereo headset is connected to a Bluetooth® device the LED will provide the following status indications on the headset.

LED Indicator	Headset Status
LED flashes red and blue alternately	Pairing mode
Blue LED flashes once every 3 seconds	Not connected to a Bluetooth® device
Blue LED flashes twice every 5 seconds	Connected to a HFP device or A2DP device
Blue LED flashes 3 times every 5 seconds	Connected simultaneously to a HFP device and A2DP device
Blue LED flashes twice or 3 times every 5 seconds	Calling in process
Blue LED flashes twice every 4 seconds	Incoming call
Blue LED flashes once every 5 seconds	Call in process
Red LED flashes twice every 20 seconds	Battery charge is low

Stereo Headset Status Tones

When the stereo headset is connected to a Bluetooth® device the LED will provide the following status indications on the headset.

Tone	Headset Status
Two short tones	Entering pairing mode
Two tones every 5 seconds	Two tones every 5 second during a call indicates the microphone is muted
Three tones every 20 seconds	Battery charge is low

CARE AND MAINTENANCE

The following recommendations will ensure you get the maximum use and enjoyment from your stereo headset.

- Do not expose the headset to liquid, moisture or high humidity to avoid damaging internal circuitry.
- Don't use abrasive cleaning solvents to clean the headset.
- Do not expose the headset to extremely high or low temperature as this can destroy the battery or distort certain plastic parts.
- Don't attempt to disassemble the headset.

SPECIFICATIONS

Bluetooth® specification	Bluetooth® V2.1+EDR
Bluetooth® profiles	HSP, HFP, A2DP and AVRCP
Operating distance	30 Feet (10 meters), Class II
Operating time	Music: Up to 10 hours Talk: Up to 11 hours
Standby time	200 hours
Charging input	DC 5A 130mA
Charging time	Approximately 3 hours
Dimensions	6.22 x 6.14 x 2.16 inches (158x156x55mm)
Weight	3.63 ounces (103 grams)



12 MONTH LIMITED WARRANTY

Applies to Audiovox Mobile Video Products

AUDIOVOX ELECTRONICS CORP. (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair labor. A game controller, if supplied, is similarly warranted for ninety (90) days.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to digital memory/media devices, gaming devices, discs, speakers, accessories, or vehicle electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Audiovox Electronics Corporation, 150 Marcus Blvd., Hauppauge, New York 11788 • 1-800-645-4994

128-5495F



For Customer Service
Visit Our Website At
www.audiovoxproducts.com
Product Information, Photos,
FAQ's Owner's Manuals



AUDIOVOX
ELECTRONICS CORP.

128-9135