

Code Lists

Liste des codes

Lista de códigos

TV	
Admiral.....	0093, 0463
Advent.....	0761, 0783, 0815, 0817
Aiko.....	0092
Akai.....	0812, 1675, 0702, 0030, 0672
Albatron.....	0843
America Action.....	0180
Anam.....	0180
AOC.....	0030, 1365, 2014
Apex Digital.....	0748, 0879, 0765
Audiovox ..	0451, 0180, 0092, 0802, 0846, 0875, 1937, 1951, 1952
Aventura.....	0171
Axon.....	1937
Bell & Howell.....	0154, 0016
BenQ.....	1032, 1315
Bradford.....	0180
Broksonic.....	0236, 0463
Candle.....	0030, 0056
Carnivale.....	0030
Carver.....	0054
Celebrity.....	0001
Celera.....	0765
Changhong.....	0765
Citizen.....	0060, 0030, 0092, 0056
Clarion.....	0180
Commercial Solutions.....	1447, 0000
Concerto.....	0056
Contec.....	0180
Craig.....	0180
Crosley.....	0054
Crown.....	0180
Curtis Mathes....	0000, 0054, 0154, 0451, 0093, 0060, 0702, 0030, 0145, 0166, 0016, 0056, 1147, 1347
CXC.....	0180
Cytron.....	1326
Daewoo.....	0451, 0092, 1661, 0661, 0672
Dell.....	1264, 1080, 1178, 1863
Denon.....	0145
Diamond Vision.....	1997
Dumont.....	0017
Durabrand.....	0463, 0180, 0178, 0171, 1034
Dynex.....	1463, 1810, 2184
Electroband.....	0001
Electrograph.....	1755
Electrohome.....	0463
Emerson.....	0154, 0236, 0463, 0180, 0178, 0171, 1394, 1963
Emprex.....	1422
Envision.....	0030, 0813, 1365, 2014
ESA.....	0812, 0171, 1963
Fisher.....	0154, 0159
Fujitsu.....	0809, 0683, 0853

Funai.....	0180, 0171, 1271, 1963
Futurtech.....	0180
Gateway.....	1755, 1756
GE.....	1447, 0000, 0051, 0451, 0178, 0021, 1347
GFM.....	0171, 1963, 2167
Gibraltar.....	0017, 0030
Go Video.....	0886
GoldStar.....	0178, 0030
Grunpy.....	0180
Haier.....	1034
Hallmark.....	0178
Hannspree.....	1745
Harman/Kardon.....	0054
Harvard.....	0180
Havermy.....	0093
Helios.....	0865
Hello Kitty.....	0451
Hewlett Packard.....	1494, 1502
Hisense.....	0748
Hitachi.....	1643, 1145, 0145, 0016, 0056
HP.....	1494, 1502
Hyundai.....	0849
iLo.....	1286, 1603, 1684, 1990
Infinity.....	0054
Initial.....	1603, 1990
Insignia.....	1564, 0171, 1204, 1326, 1517, 1641, 1710, 1963, 2002
Inteq.....	0017
JBL.....	0054
JCB.....	0001
Jensen.....	0761, 0815, 0817
JVC.....	0053, 0731, 1253, 1601, 1774
KDS.....	1498
KEC.....	0180
Kenwood.....	0030
KLH.....	0765
KTV.....	0180, 0030
LG.....	1423, 1265, 0178, 0856, 1178
Logik.....	0016
Luxman.....	0056
LXI.....	0000, 0054, 0154, 0156, 0178
MAG.....	1498
Magnavox.....	1454, 1866, 0054, 0030, 0096, 0802, 1198, 1254, 1365, 1963, 1990
Majestic.....	0016
Marantz.....	0054, 0030, 0704, 0855
Matsushita.....	0250, 0650
Maxent.....	1755
Megatron.....	0178, 0145
Memorex.....	0154, 0463, 0150, 0178, 0016
MGA.....	0150, 0178, 0030
Midland.....	0000, 0017, 0051
Mintek.....	1603, 1990
Minutz.....	0021
Mitsubishi.....	1250, 0093, 0150, 0178, 0836
Monivision.....	0843
Motorola.....	0093
MTC.....	0060, 0030, 0056
Multitech.....	0180
NAD.....	0156, 0178, 0056, 0866, 1156
NEC.....	0030, 0056, 0882, 1704, 1797

NetTV.....	1755
Nikko.....	0178, 0030, 0092
Norcent.....	0748, 0824, 1365
Norwood Micro.....	1286
NTC.....	0092
NuVision.....	2158
Olevia.....	1610, 1144, 1240, 1331
Onwa.....	0180
Optimus.....	0250, 0154, 0166, 0650
Optoma.....	2161
Optonica.....	0093
Orion.....	0236, 0463, 1463
Panasonic.....	0250, 1480, 0051, 0650
Penney.....	0000, 0156, 0051, 0060, 0178, 0030, 0021, 1347
Petters.....	1523
Philco.....	0054, 0030, 0096
Philips.....	1454, 0054, 0690, 1744, 1867
Pilot.....	0030
Pioneer.....	1457, 0166, 0679, 0866, 1260
Polaroid.....	1523, 0765, 0865, 1276, 1286, 1314, 1326, 1328, 1341, 1498, 1766, 2002, 2121
Portland.....	0092
Prima.....	0761, 0783, 0815, 0817
Prism.....	0051
Proscan.....	1447, 0000, 1347, 2256
Proton.....	0178
Proview.....	1498
Pulsar.....	0017
Quasar.....	0250, 0051, 0650
RadioShack.....	0000, 0154, 0180, 0178, 0030, 0056
RCA.....	0000, 1547, 1447, 0679, 1047, 1147, 1247, 1347, 1781, 2002, 2187, 2247
Realistic.....	0154, 0180, 0178, 0030, 0056
Runco.....	0017, 0030
Sampo.....	1755, 0030
Samsung ..	0812, 0060, 0702, 0178, 0030, 0056, 0766, 0814, 1060
Sansui.....	0463
Sanyo.....	0154, 0159, 1142
Scotch.....	0178
Scott.....	0236, 0180, 0178, 1711
Sears.....	0000, 0054, 0154, 0156, 0178, 0171, 0056, 0159
Sharp.....	0818, 0093
Sheng Chia.....	0093
Signature.....	0016
Sony.....	0001, 0810, 1685
Soundesign.....	0180, 0178
Sova.....	1952
Soyo.....	1520, 1826
Spectroniq.....	1498
Squareview.....	0171
SSS.....	0180
Starlite.....	0180
Studio Experience.....	0843
Superscan.....	0093, 0864
Supreme.....	0001
SVA.....	0748, 0865
Sylvania.....	1864, 0054, 0030, 0171, 0096, 1271, 1314, 1394, 1886, 1963
Symphonic.....	0180, 0171
Syntax.....	1610, 1144, 1240, 1331

Tandy.....	0093
Tatung.....	1286, 1756
Technics.....	0250, 0051
Techview.....	0847
Techwood.....	0051, 0056
Teknika.....	0054, 0180, 0150, 0060, 0092, 0016, 0056
Telefunken.....	0702, 0056
TMK.....	0178, 0056
TNCi.....	0017
Toshiba.....	1524, 0154, 0156, 1256, 1265, 0060, 0650, 0845, 1156, 1356, 1656, 1704
TruTech.....	1723
TVS.....	0463
US Logic.....	1286
Vector Research.....	0030
Victor.....	0053
Vidikron.....	0054
Vidtech.....	0178
Viewsonic.....	1755, 0857, 0864, 0885, 1627, 2014
Viore.....	1684
Vizio.....	1758, 0864, 0885, 1756
Wards.....	0054, 0178, 0030, 0016, 0021, 0056, 0096, 0866, 1156
Waycon.....	0156
Westinghouse.....	1712, 0885, 0889, 1282, 1577
White Westinghouse.....	0463
Wyse.....	1365
Yamaha.....	0030, 0769
Zenith.....	0017, 0463, 1265, 0178, 0092, 0016

Audio — Amplifier / Amplificateur / Amplificador	
Durabrand.....	1561
GE.....	0078
Lenoxx.....	1561
Soundesign.....	0078
Wards.....	0078
Yamaha.....	0354

Audio Accessories / Accessoires de audio / Accesorios de audio

Accurian.....	1106
Altec Lansing.....	0607
Apple.....	1115
DLO.....	1155
Griffin.....	1891
iDeck.....	1106
iHome.....	2152
Monitor Audio.....	1106
Polk Audio.....	2228
Roku.....	1828
Yamaha.....	2021

Audio — Receiver / Récepteur / Receptor

Aiwa.....	1405
Anam.....	1609
Audiotronic.....	1189
Bose.....	1229, 1933
Carver.....	1189
Denon.....	1360, 2857
Harman/Kardon.....	1304, 1306
Insignia.....	1030, 1077, 2169, 2175
Integra.....	1298, 1320, 1805
JBL.....	1306
JVC.....	2331
Kenwood.....	1313
LG.....	2197
Magnavox.....	1189, 1269
Marantz.....	1189, 1269
Onkyo.....	0842, 1298, 1320, 1805
Panasonic.....	1308, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips.....	1189, 1269, 1266, 2311
Pioneer.....	1384, 1935
Proscan.....	0000
RCA.....	0000, 1609, 1511, 2041
Samsung.....	1295, 1500, 1868
Sherwood.....	1077, 2169
Sherwood Newcastle.....	2169
Sony.....	1759, 1058, 1441, 1258, 1622, 1558, 1658, 1758, 1858, 2172
Sunfire.....	1313
Technics.....	1308
Thorens.....	1189
Yamaha.....	0176, 1176, 1276, 1331, 1375, 2061

VCR-DVR / Magnéscope - DVR

ABS.....	1972
Accurian.....	0001
Adventura.....	0001
Aiwa.....	0001
Alienware.....	1972
Broksonic.....	1479
Citizen.....	1278
Curtis Mathes.....	2000, 0162, 1035
CyberPower.....	1972
Daewoo.....	1278
Dell.....	1972
DirecTV.....	0739
Durabrand.....	0039
Dynatech.....	0001
Emerson.....	0001, 0043, 0593, 1278, 1479, 1593
Funai.....	0001, 0593, 1593
Garrard.....	0001
Gateway.....	1972
GE.....	2000, 0202, 0807, 1035, 1060
GFM.....	1593
Go Video.....	0614
GoldStar.....	1237
Gradiente.....	0001
Harley Davidson.....	0001
Headquarter.....	0046
Hewlett Packard.....	1972
Hitachi.....	0001
Howard Computers.....	1972
HP.....	1972
Hughes Network Systems.....	0739
Humax.....	0739
Hush.....	1972
iBUYPOWER.....	1972
JVC.....	0067
Kenwood.....	0067
Linksys.....	1972
Lloyd's.....	0001
Magnasonic.....	0593, 1278
Magnavox.....	0039, 0001, 0593, 1593, 1781
Matsushita.....	0162, 1162
Media Center PC.....	1972
Memorex.....	0162, 0039, 0001, 0046, 1162, 1237, 1262
MGA.....	0043
Microsoft.....	1972
Mind.....	1972
Mitsubishi.....	0067, 0043, 0807
MTC.....	0001
Multitech.....	0001
NEC.....	0067
Niveus Media.....	1972
Northgate.....	1972
Optimus.....	0162, 0593, 1162, 1262
Orion.....	1479
Panasonic.....	0162, 0614, 0616, 1035, 1162, 1262
Penney.....	1035, 1237
Philips.....	0739, 0618
Pioneer.....	0067
Presidian.....	1593

Proscan.....	2000, 0202, 1060
Pulsar.....	0039
Quarter.....	0046
Quartz.....	0046
Quasar.....	0162, 1035, 1162
RadioShack.....	0001
RCA.....	2000, 0202, 0807, 0880, 1035, 1060
Realistic.....	0001, 0046
ReplayTV.....	0614, 0616
Ricavision.....	1972
Runco.....	0039
Samsung.....	0739, 1014
Sanky.....	0039
Sansui.....	0001, 0067, 1479
Sanyo.....	0046
Scott.....	0043
Sears.....	0001, 0046, 1237
Sharp.....	0807, 0848
Sonic Blue.....	0614, 0616
Sony.....	1232, 0001, 0636, 1972
Stack 9.....	1972
Sylvania.....	0001, 0043, 0593, 1593, 1781
Symphonic.....	0001, 0593, 1593
Systemax.....	1972
Tagar Systems.....	1972
Teac.....	0001
Technics.....	0162
Teknika.....	0001
Thomas.....	0001
Tivo.....	0739, 0618, 0636, 1996
Toshiba.....	0043, 0845, 1145, 1972, 1996
Touch.....	1972
Viewsonic.....	1972
Villain.....	0001
Voodoo.....	1972
Wards.....	2000, 0001
XR-1000.....	0001
Zenith.....	0039, 0001, 1479
ZT Group.....	1972

DVD

Accurian.....	0675, 1416
Aiwa.....	0641
Akai.....	0695, 0899
Allegro.....	0869
Apex Digital.....	0672, 0717, 0794, 0796, 0797, 0830, 1056, 1061
Argo.....	1023
Audiovox.....	1041, 1121, 1122
BBK.....	1224
Bel Canto Design.....	1571
Blaupunkt.....	0717
Blue Parade.....	0571
Bose.....	2023
Broksonic.....	0695, 0868
Cinea.....	0831
CineVision.....	0869
Citizen.....	0695
Coby.....	0778, 1086, 1107, 1177
Craig.....	0831
CyberHome.....	0816, 0874, 1023, 1024, 1129, 1502, 1537
Daewoo.....	0784, 0869, 1169, 1172
Denon.....	0490, 2258
Diamond Vision.....	1316
Disney.....	0675, 1270
Durabrand.....	1127
DVD2000.....	0521
Emerson.....	0675, 0821, 1268
ESA.....	0821, 1268
Funai.....	0675, 1268, 1334
GE.....	0000, 0815, 0717
GFM.....	0675, 1268
Go Video.....	0744, 0715, 0741, 0869, 1075
GoldStar.....	0741
Greenhill.....	0717
Harman/Kardon.....	0702, 1229
Hello Kitty.....	0831
Hitachi.....	0573, 0664
Hiteker.....	0672
iLo.....	1348
Initial.....	0717
Insignia.....	0675, 1268, 2095, 2428
Integra.....	0627, 1769, 2147
JBL.....	0702
JSI.....	1423
JVC.....	0558, 0623, 0867, 1164
Kenwood.....	0490, 0534
KLH.....	0717
Konka.....	0711
Koss.....	0651, 1423
Lasonic.....	0798
Lenoxx.....	1127
LG.....	0741, 0869
LiteOn.....	1416, 1656
Magnavox.....	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1506
Marantz.....	0539, 2414
Memorex.....	0695, 0831, 1270
Microsoft.....	0000, 2083
Mintek.....	0839, 0717
Mitsubishi.....	1521, 0521

NAD.....	0741
Nesa.....	0717
Norcent.....	1107
Olevia.....	2331
Onkyo.....	0503, 0627, 1769, 2147
Oppo.....	0575, 1224
Oritron.....	0651
Panasonic.....	0490, 0632, 0703, 1490, 1641, 1762, 1907
Philco.....	0675
Philips.....	0503, 0539, 2056, 0646, 0675, 1267, 1340, 1354, 2084, 2334, 2434
Pioneer.....	0525, 0571, 0142, 0631, 0632, 1571, 2442
Polaroid.....	1061, 1086, 1316
Polk Audio.....	0539
Presidian.....	0675
Proscan.....	0000
Motorola.....	0869
ProVision.....	0778
Qwestar.....	0651
RCA.....	0000, 0571, 0717, 0822, 1022, 1132, 1769
Rio.....	0869
Rotel.....	0623
Sampo.....	0752
Samsung.....	0490, 0573, 0199, 0820, 0899, 1075, 1932
Sansui.....	0695
Sanyo.....	0695, 0873
Sharp.....	0630, 0675, 0752, 2250
Shinsonic.....	0533, 0839
Sonic Blue.....	0869
Sony.....	0533, 1533, 0864, 1033, 1070, 1431, 1516
Sova.....	1122
Superscan.....	0821
Sylvania.....	0675, 0821, 1268
Symphonic.....	0675, 0821
Technics.....	0490, 0703
Theta Digital.....	0571
Tivo.....	1503
Toshiba.....	0503, 0695, 1045, 1154, 1503, 1769
Urban Concepts.....	0503
US Logic.....	0839
Vizio.....	1064
Xbox.....	0000, 2083
Yamaha.....	0490, 0539, 0545
Zenith.....	0503, 0741, 0869

Satellite/Satélite

Bell ExpressVu.....	0775
DirecTV.....	1377, 0392, 0000, 0639, 1142, 0247, 0749, 1749, 1856, 1076, 1442, 1609
Dish Network System.....	0775, 1505, 1775
Dishpro.....	0775, 1505, 1775
Echostar.....	0775, 1505, 1775
Expressvu.....	0775, 1775
GE.....	0000
General Instrument.....	0869
GOI.....	0775, 1775
HTS.....	0775, 1775
Hughes Network Systems.....	1142, 0749, 1749, 1442
JVC.....	0775, 1775
Mitsubishi.....	0749
Motorola.....	0869
Next Level.....	0869
Panasonic.....	0247, 0701
Philips.....	1142, 0749, 1749, 1076, 1442
Proscan.....	0392, 0000
RadioShack.....	0869
RCA.....	0000, 0855, 0143
Samsung.....	1377, 1276, 1442, 1609
Sony.....	0639
Star Choice.....	0869
Tivo.....	1142, 1442
Toshiba.....	0749, 1749, 0790
Voom.....	0869
Zenith.....	1856

Cable / Câble

Amino.....	1602, 1822
Cisco.....	1877, 0877, 1982
Comcast.....	1982
Digeo.....	1187, 2187
Director.....	0476
General Instrument.....	0476
Homecast.....	2301
i3 Micro.....	1602
Jerrold.....	0476
Motorola.....	1376, 0476, 1187
Myrio.....	1602, 1822
Pace.....	1877
Panasonic.....	1982
Pioneer.....	1877, 0877
RCA.....	1256
Scientific Atlanta.....	1877, 0877
Sejin.....	1602
Thomson.....	1256

Video Accessories (Media Centers, Videogames, etc.) / Accessoires de vidéo (centres de médias, jeux vidéo, etc.) / Accesorios de vídeo (Centros de entretenimiento, videoconsolas, etc.)

2Wire.....	2045
Access HD.....	2185
ADB.....	2254, 2586
Airlink 101.....	2491
Alpha Digital.....	2185
Amino.....	1481, 2482
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858, 2045
CASTi.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Insignia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Microsoft.....	2049
Motorola.....	1998, 0858
Philco.....	1563
Popcorn Hour.....	2260
RCA.....	0799, 2325, 2454
Roku.....	2371
Sansonic.....	2348
Scientific Atlanta.....	0858, 2345
SureWest.....	1481
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Verizon.....	2378
Vudu.....	2298
Winegard.....	2454
Xbox.....	2049
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

Digital TV Converter Boxes / Boîtes de conversion pour TV numérique / Convertidores Digitales

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	2185
Apex Digital.....	2478
Artec.....	2490
CASTi.....	2305
Channel Master.....	2365
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Epson.....	1563
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Insignia.....	1415
KoolConnect.....	1481
Lasonic.....	2348
LG.....	1415
Magnavox.....	1563
Memorex.....	2486
MicroGEM.....	2489
Microsoft.....	2049
Motorola.....	1998, 0858
Philco.....	1563
Popcorn Hour.....	2260
RCA.....	0799, 2325, 2454
Roku.....	2371
Sansonic.....	2348
Scientific Atlanta.....	0858, 2345
SureWest.....	1481
Sylvania.....	1563
Tivax.....	2185
Ventura.....	2454
Venturer.....	2454
Verizon.....	2378
Vudu.....	2298
Winegard.....	2454
Xbox.....	2049
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

© 2009 Audiovox Accessories Corporation
111 Congressional Blvd., Suite 350
Carmel, IN 46032

RCU600_Codes_00

Trademark(s) © Registered / Marque(s) de commerce déposée(s)® /
Marca(s) Registrada(s)