





Installation Manual: Honda CRV Power Lift Gate System






NOTE: Installation Precaution


- 1. It is recommended to have this product installed by a professional to avoid damage caused by improper installation.
- 2. Do not attempt to disassemble or modify any components included within the kit. Unapproved modifications or evidence of tampering will void any warranty included with the product.
- 3. Before installation, inspect the vehicle's controls and interior/exterior for any damage or malfunctioning components. Report any damage or non conformities to the customer prior to installing the product.
- 4. Inspect the factory lift gate for proper operation and function of lights before installing this product. Improper opening or closing of the lift gate may interfere with the functionality of the Power Lift Gate System.
- 5. It is recommended to remove or cover any item of clothing (belt buckles, jeans rivets, buttons, etc) prior to installation of this accessory to prevent damage incurred to the vehicle during the installation.
- 6. Interior panels that have been removed should be set aside somewhere safe during the installation process to avoid damage.
- 7. When routing and securing wiring harnesses, care should be exercised to avoid any hot, sharp, or moving objects in the vehicle such as steering column, pedals, dash bracing, HVAC components, etc.
- 8. Do not deviate from methods of installation in this document. Any damage caused by improper wire routing, incorrect connections, wiring, etc. is not covered under the warranty.
- 9. Disconnect the negative (-) battery terminal before proceeding to installation. Wait at least 2 minutes after disconnecting the negative (-) battery terminal to disable the SRS and other systems in the vehicle. Any damage caused from failure to disconnect the battery is not covered under the warranty.
- 10. After installation, you must manually close the lift gate to initialize the Power Lift Gate System.

Wiring Details



Page 3 of 18

Wiring Details



Page 4 of 18

PREPARING FOR INSTALLATION

INSTALLATION PREPARATION

Before starting installation

- 1. Familiarize yourself with the installation instructions.
- 2. Inspect kit components to verify everything is present, there is no damage, and to familiarize yourself with the parts.

VEHICLE PREPARATION

- 1. Place protective coverings on vehicle.
- 2. Apply protective tape to all points before prying.
- 3. "IMPORTANT.....IMPORTANT"




<u>Disconnect Negative Battery</u> Cable

INSTALLATION:

1. Lift and remove the luggage compartment floor board.

2. Disengage the clips holding the cloth trim from the back of the seats from the floor trim garnish.








3. Disengage the clips and remove the luggage compartment trim garnish from the floor.



4. Use a moulding remover, gently disengage the claws and remove the LH side access panel behind the LH rear seat.



5. Disengage the claws, and remove the driver's side rear door scuff plate.



6. Carefully disengage the claws and remove the LH rear side trim panel.

7. Remove the hook by depressing the black spot in the middle and pulling outward.

8. Remove the cover off of the handle. Then remove the (2) screws securing the release handle to the wall.

9. Remove the screw to remove the LH tie-down cleat. Repeat for the RH side.










10. Press the center of the clip, and lift up to disengage the clips from the rear luggage compartment opening garnish plate.

11. Carefully pry to disengage the clips to remove the luggage compartment opening garnish plate.


12. Carefully pry to disengage all of the clips, and remove the LH inside quarter panel trim panel.








13. Carefully pry to disengage the clips securing the upper trim panel to access the connectors behind it. It is not necessary to completely remove the trim panel.








14. Connect the supplied T-Harness to the OEM lift gate latch/lock connector.

15. Using a Nylon Trim Tool, carefully disengage the clips and remove both the left and right side vent registers.

16. Remove the (2) screws and disengage the claws securing the factory radio. Disconnect any electrical connectors and remove the radio from the dash.

17. Using the supplied T-Harness, connect to the factory harness located behind the radio. After making the connection, route the harness towards the driver's side lower dash area.






Screw Locations



18. Using a Nylon Removal Tool, carefully disengage the claws and remove the driver's side trimpanel.

19. Carefully pry on the driver's dash trim panel to disengage the clips and remove it. Set aside where it will not get damaged.


20. Remove the screw, then disengage the clips to remove the driver's side lower dash finish panel.







21. Locate the large wire harness up near the dash brace. Locate the large WHITE wire within this harness. Use the supplied splice-clip and attach the YELLOW power wire from the Power Lift Gate Kit to the WHITE power wire.



22. Drill a hole and mount the dash mounted open/ close button in the driver's lower dash finish panel, as pictured.



23. Begin routing the main wiring harness down the driver's side of the vehicle, towards the control module mounting location in the rear quarter panel.



24. Remove the screws securing the tail lamp to the vehicle's body. Then disengage the clips to loosen the tail lamp assembly. Disconnect the wiring harness, remove, and set the tail lamp assembly aside where it will not be damaged.

Repeat for other side tail lamp assembly.

- 25. Using a helper or supporting brace, support the lift gate in the full opened position.
- 26. Using a pry tool, remove the lower clip on the end of the OEM gas support struts for the lift gate.

Exercise caution when removing the support struts, as the lift gate is very heavy once removed.

- 27. Using a pry tool, remove the upper clip on the end of the OEM gas support strut for the lift gate, and remove the support strut.
- 28. Repeat for the opposite side.








29. Remove the OEM support strut mounting bracket, and replace with the one supplied in the kit. Note the LEFT and RIGHT sides when replacing the brackets.

30. Remove the ball mount for the OEM support strut on the lift gate structure. Replace with the ball mounts supplied in the kit.

31. Install the Power Lift Gate Motors to the new mounts, verifying that the clips are fully engaged. Ensure the LEFT and RIGHT motors are mounted on the correct sides. Then reinstall the tail lamp assemblies, taking care to locate the Power Lift Motor in the slot on the tail lamp assembly.







- 32. Remove the tape securing the wire loom to the tail lamp rubber wiring boot. Route the Power Lift Gate Motor's wiring harness through the tail lamp wiring boot, to the interior of the vehicle.
- 33. Once wire is completely pulled through wiring boot, re-tape with waterproof electrical tape to prevent water leaks.


34. Route the RH Lift Motor's wiring harness towards the driver's side of the vehicle, following the illustrated to the path. Secure to the vehicle's body along the routing path.

35. Make all appropriate connections to the control module. Then, using the supplied mounting bracket secure the control module to the vehicle's body structure in the LH rear quarter panel area. Note the location of the rear seat release handle for reference.






Rear Seat Release Handle Mounting Location



36. Disengage the claws and remove the lift gate center trim garnish.

37. Disengage the claws and remove the lift gate side trim garnish. Repeat for other side.



38. Remove the screw inside the pull handle. Then carefully pry to disengage the claws and remove the pull handle.



39. Disengage the clips and remove the lift gate interior trim panel.



40. Route the open/close button's wiring harness up through the OEM wire harness boot and into the lift gate.

41. Drill a hole in the pull handle and mount the open/close button on the left side of the handle.

42. For 2013 Model Year vehicles, mount the open/close button on the lift gate interior trim panel as shown.







THESE POINTS MUST BE CHECKED TO ENSURE A QUALITY INSTALLATION

Ш	Head Light If the warning lights remains on, it may	Massage Seats (if equipped)
	indicate a system malfunction.	Power Side Mirrors (if equipped)
	High Beams	Side Mirror Defogger (if equipped)
	Turn Signal Lights	Front Windshield Defogger (if equipped)
	Tail Lights	Navigation System (if equipped)
	Stop Lights	Rear Sunshade (if equipped)
	Backup Lights	Cruise Control Light (if equipped)
	Hazard Lights	Steering Wheel Audio Control
	Marker Lights	(if equipped)
	Dome/Courtesy Lights	HVAC
	Panel/Switch Illumination	Power Locks (if equipped)
	Accessory Controls/Illumination (if equipped)	Power Windows (if equipped)
	Rear Window Defogger	Gauges
	(if equipped) Key Sensor Buzzer	Front Wiper/Washer
	Fog Lights (if equipped)	Hood Latch Release
	Day Time Running Lights (if equipped)	Passenger Air Bag Switch (if equipped)
	Trunk/Tailgate/Bed Lights (if equipped)	Rollover Side Curtain Air Bag Switch (RSCA)
	Glove Box Light (if equipped)	Horn
	ABS Light (if equipped)	Seat Belt Warning Light
	Rear Wiper/Washer (if equipped)	If the warning lights remains on, it may indicate a system malfunction.
		Air Bag Warning Light
	Clock (if equipped)	If the warning lights remains on, it may indicate a system malfunction.
	Accessory Power Socket	Lamp Failure Sensor
$\overline{}$	(if equipped)	If the warning lights remains on, it may indicate a system malfunction.
	Starter	Track/Skid Control Light (if equipped)
	Audio/Video (if equipped)	 If the warning lights remains on, it may indicate a system malfunction.
	Power Sliding Door (if equipped)	Tire Pressure Monitoring System (TPMS)
Ш	i one: onaing boot (if equipped)	Prior to TPMS activation and Pre-Delivery Service (PDS) of the vehicle the TPMS light will
	Convenience Memory Settings (if equipped)	blink when IG is turned on. After TPMS activa- tion and PDS of the vehicle the TPMS light will illuminate for a few seconds and go off when IG
	Heated Seats (if equipped)	is turned on.